



SERVICE MANUAL

MX775
MX800
MX825

**MX775, MX800, MX825
SERVICE MANUAL
©2016 by Yamaha Motor
Corporation, U.S.A.
1st Edition, December 2016
All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor
Corporation, U.S.A.
is expressly prohibited.
LIT-19616-02-37**

IMPORTANT

This manual was produced by the Yamaha Motor Powered Products Co., Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha machines should have a basic understanding of mechanics and the techniques to repair these types of machines. Repair and maintenance work attempted by anyone without this knowledge is likely to render the machine unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the machine will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his machine and to conform to federal environmental quality objectives.

Yamaha Motor Powered Products Co., Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

TIP

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
 - Designs and specifications are subject to change without notice.
-

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following notations.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

NOTICE

A NOTICE indicates special precautions that must be taken to avoid damage to the machine or other property.

TIP

A TIP provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic.

Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title is shown at the top of each page “1”.
- Sub-section titles appear in smaller print than the section title “2”.
- To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section “3”.
- Numbers are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step “4”.
- Symbols indicate parts to be lubricated or replaced “5”.

Refer to SYMBOLS.

- A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc. “6”. This step explains removal procedure only. For installation, reverse the steps.
- Jobs requiring more information (such as special tools and technical data) are described sequentially “7”.

1

OIL PUMP

OIL PUMP

3

4

5

6

Order	Job/Parts to remove	Qty	Remarks
Removing the oil pump			
	Cylinder head assembly		Remove the parts in the order listed. Refer to "CYLINDER HEAD COVERS, CYLINDER HEADS" on page 3-26.
1	Collar	1	
2	Crankcase cover 2	1	
3	Dowel pin	2	
4	Relief valve	1	
5	Oil pump cover	1	
6	Oil strainer cover	1	
7	Oil strainer	1	
8	Inner rotor	1	
9	Outer rotor	1	
10	Oil seal	1	
11	Oil pressure switch	1	

3-33

OIL PUMP

DISASSEMBLING THE OIL PUMP

- Remove:
 - Crankcase cover 2
- Remove:
 - Relief valve "1"
- Remove:
 - Oil pump cover "1"
- Remove:
 - Oil strainer cover "1"
 - Oil strainer "2"
 - Inner rotor "3"
 - Outer rotor "4"

CHECKING THE OIL PUMP

- Check:
 - Inner rotor "1"
 - Outer rotor "2"
 Cracks/damage/wear ☒ Replace the defective part(s).
- Check:
 - Oil strainer "1"
 - Oil strainer cover "2"
 Damage ☒ Replace, Contaminants ☒ Clean with solvent.














3-34

SYMBOLS

The following symbols are used in this manual for easier understanding.

TIP

The following symbols are not relevant to every machine.

SYMBOL	DEFINITION	SYMBOL	DEFINITION
	Filling fluid		Lubricant
	Special tool		Tightening torque
	Wear limit, clearance		Engine speed
	Electrical data		Replace the part with a new one.
	Lithium-soap base grease		Molybdenum disulfide grease
	Engine oil		Silicone fluid
	Apply locking agent (LOCTITE®)		

INDEX

GENERAL INFORMATION

1

**PERIODIC CHECKS AND
ADJUSTMENTS**

2

ENGINE

3

FUEL

4

ELECTRICAL

5

TROUBLESHOOTING

6

SPECIFICATIONS

7

MEMO

TABLE OF CONTENTS

GENERAL INFORMATION

MACHINE IDENTIFICATION	1-1
SERIAL NUMBER	1-1
STARTING SERIAL NUMBER.....	1-1
DIMENSIONS	1-2
TOP	1-2
MOUNTING BASE	1-2
REAR.....	1-3
REAR (For models equipped with a muffler)	1-3
RIGHT SIDE	1-4
RIGHT SIDE (For models equipped with a muffler)	1-4
IMPORTANT INFORMATION	1-5
PREPARATION FOR REMOVAL AND DISASSEMBLY	1-5
CAUTION ON SERVICE.....	1-5
NOTES ON SERVICE	1-5
ALL REPLACEMENT PARTS.....	1-6
GASKETS, OIL SEALS, AND O-RINGS	1-6
BEARINGS AND OIL SEALS	1-7
BASIC SERVICE INFORMATION	1-7
ELECTRICAL SYSTEM.....	1-7
SPECIAL TOOLS AND TESTERS	1-11

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION	2-1
MAINTENANCE INTERVALS CHART	2-1
PERIODIC MAINTENANCE/ LUBRICATION INTERVALS	2-1
PERIODIC MAINTENANCE	2-2
SPARK PLUGS.....	2-2
MUFFLER (For models equipped with a muffler)	2-3
ENGINE OIL LEAKAGE	2-4
ENGINE OIL LEVEL.....	2-5
REPLACING THE ENGINE OIL	2-6
FUEL LEAKAGE.....	2-8
FUEL FILTER	2-8

OIL COOLER	2-9
AIR FILTER ELEMENT	2-9
ADJUSTING THE VALVE CLEARANCE	2-9
CYLINDER HEADS DECARBONIZATION	2-13
ENGINE SPEED	2-14
ADJUSTING THE ENGINE SPEED....	2-15
LOW ENGINE SPEED (Replace the throttle body)	2-16
FITTINGS AND FASTENERS.....	2-16

ENGINE

ENGINE INSPECTION	3-1
MEASURING THE COMPRESSION PRESSURE	3-1
AIR FILTER	3-3
MUFFLER (For models equipped with a muffler)	3-4
OIL COOLER	3-5
REMOVING THE OIL COOLER.....	3-6
CHECKING THE OIL COOLER.....	3-6
INSTALLING THE OIL COOLER	3-6
ECU, RECTIFIER/REGULATOR, AND FUSES	3-8
INSTALLING THE FUSES	3-9
IGNITION COILS	3-10
CASE AND FAN	3-11
REMOVING THE CASE AND FAN	3-12
CHECKING THE CASE AND FAN.....	3-13
INSTALLING THE CASE AND FAN	3-13
FLYWHEEL AND STATOR COIL ASSEMBLY	3-15
REMOVING THE FLYWHEEL AND STATOR COIL ASSEMBLY	3-16
CHECKING THE FLYWHEEL AND STATOR COIL ASSEMBLY	3-17
INSTALLING THE FLYWHEEL AND STATOR COIL ASSEMBLY	3-17
INSTALLING THE CRANKSHAFT POSITION SENSOR.....	3-19

CYLINDER HEAD COVERS, CYLINDER HEADS.....3-20

CYLINDER HEAD #1 3-20
CYLINDER HEAD #2 3-22
CHECKING THE ROCKER ARMS
AND ROCKER ARM SHAFTS..... 3-24
CHECKING THE PUSH RODS 3-24
REMOVING THE CYLINDER
HEADS 3-24
CHECKING THE CYLINDER
HEADS 3-24
INSTALLING THE CYLINDER HEAD
ASSEMBLY 3-25

VALVES3-27

REMOVING THE VALVES AND
VALVE SPRINGS..... 3-28
CHECKING THE VALVES AND
VALVE SPRINGS..... 3-28
CHECKING THE VALVE SEATS 3-30
VALVE LAPPING 3-31
INSTALLING THE VALVES AND
VALVE SPRINGS..... 3-32

OIL PUMP.....3-33

DISASSEMBLING THE OIL PUMP 3-34
CHECKING THE OIL PUMP 3-34
CHECKING THE RELIEF VALVE 3-35
CHECKING THE CRANKCASE
COVER 2 3-35
INSTALLING THE OIL PRESSURE
SWITCH 3-35
ASSEMBLING THE OIL PUMP 3-36
INSTALLING THE CRANKCASE
COVER 2 3-37

**PISTONS, CAMSHAFT, CRANKCASE,
AND CRANKSHAFT3-38**

CRANKCASE 3-38
PISTONS, CAMSHAFT, AND
CRANKSHAFT 3-40
REMOVING THE FLYWEIGHT
SHAFT ASSEMBLY AND
GOVERNOR FORK..... 3-41
DISASSEMBLING THE FLYWEIGHT
SHAFT ASSEMBLY 3-41
CHECKING THE FLYWEIGHT
SHAFT ASSEMBLY 3-41
ASSEMBLING THE FLYWEIGHT
SHAFT ASSEMBLY 3-42

INSTALLING THE FLYWEIGHT
SHAFT ASSEMBLY AND
GOVERNOR FORK 3-42
REMOVING THE CAMSHAFT AND
VALVE LIFTERS 3-43
CHECKING THE CAMSHAFT 3-43
CHECKING THE VALVE LIFTERS 3-44
CHECKING THE REED VALVE 3-45
INSTALLING THE VALVE LIFTERS
AND CAMSHAFT 3-45
INSTALLING THE COVER 1 3-45
INSTALLING THE COVER 2 3-46
CHECKING THE CRANKCASE
COVER 1 3-46
INSTALLING THE CRANKCASE
COVER 1 3-47
CHECKING THE CYLINDERS AND
PISTONS 3-47
CHECKING THE CRANKCASE 3-49
CHECKING THE PISTON PINS 3-49
CHECKING THE PISTON RINGS 3-49
CHECKING THE CRANKSHAFT 3-51
CHECKING THE CONNECTING
RODS OIL CLEARANCE 3-52
INSTALLING THE PISTONS AND
PISTON RINGS 3-52
INSTALLING THE CRANKSHAFT 3-54

FUEL

FUEL PUMPS 4-1

REMOVING THE HIGH-PRESSURE
FUEL PUMP..... 4-2
CHECKING THE LOW-PRESSURE
FUEL PUMP..... 4-3
CHECKING THE HIGH-PRESSURE
FUEL PUMP..... 4-3
INSTALLING THE HIGH-PRESSURE
FUEL PUMP..... 4-4

THROTTLE BODY ASSEMBLY 4-6

REMOVING THE THROTTLE BODY
ASSEMBLY 4-7
CHECKING THE THROTTLE BODY
ASSEMBLY 4-7
INSTALLING THE THROTTLE BODY
ASSEMBLY 4-7

FUEL INJECTORS AND INTAKE MANIFOLD	4-9
REMOVING THE FUEL INJECTORS	4-11
INSTALLING THE FUEL INJECTORS	4-12
REMOVING THE MANIFOLD ABSOLUTE PRESSURE SENSOR	4-14
INSTALLING THE MANIFOLD ABSOLUTE PRESSURE SENSOR	4-14
REMOVING THE INTAKE MANIFOLD	4-14
CHECKING THE INTAKE MANIFOLD	4-15
INSTALLING THE INTAKE MANIFOLD	4-15

ELECTRICAL

CIRCUIT DIAGRAM.....	5-1
FUEL INJECTION SYSTEM.....	5-3
FI DIAG TOOL INSTRUCTIONS	5-3
FUEL INJECTION DIAGRAM.....	5-9
ERROR CODE LIST	5-10
DIAG CODE LIST	5-11
FUEL INJECTION SYSTEM TROUBLESHOOTING.....	5-12
ELECTRICAL COMPONENTS.....	5-25
CHECKING THE SWITCH CONTINUITY	5-27
CHECKING THE FUSES	5-27
CHECKING THE OIL PRESSURE SWITCH	5-28
CHECKING MANIFOLD ABSOLUTE PRESSURE SENSOR.....	5-29
CHECKING THE THROTTLE POSITION SENSOR	5-29
CHECKING THE CRANKSHAFT POSITION SENSOR	5-30
CHECKING THE ENGINE TEMPERATURE SENSOR.....	5-31
CHECKING THE IGNITION COILS.....	5-32
CHECKING THE IGNITION SPARK GAP	5-33
CHECKING THE SPARK PLUG CAPS	5-33

CHECKING THE STATOR COIL ASSEMBLY	5-34
CHECKING THE RECTIFIER/ REGULATOR	5-35
CHECKING THE FUEL INJECTORS.....	5-35
CHECKING THE STARTER MOTOR OPERATION	5-36
ELECTRIC STARTING SYSTEM	5-37
REMOVING THE STARTER MOTOR.....	5-37
DISASSEMBLING THE STARTER MOTOR.....	5-38
CHECKING THE ARMATURE COIL ...	5-39
CHECKING THE BRUSH	5-40
CHECKING THE STARTER RELAY ...	5-40
ASSEMBLING THE STARTER MOTOR.....	5-40

TROUBLESHOOTING

ENGINE DOES NOT START.....	6-1
IGNITION SYSTEM	6-1
ELECTRIC STARTING SYSTEM	6-2
FUEL INJECTION SYSTEM	6-2
FUEL PUMP SYSTEM.....	6-2
OTHER TROUBLES.....	6-3
ENGINE STARTS BUT STALLS.....	6-3
ENGINE SPEED DOES NOT INCREASE.....	6-4
ENGINE SPEED IS UNEVEN.....	6-5
THE BATTERY IS NOT CHARGED	6-5
GOVERNOR OPERATION.....	6-6
OIL PRESSURE SYSTEM	6-6

SPECIFICATIONS

GENERAL SPECIFICATIONS	7-1
MAINTENANCE SPECIFICATIONS	7-3
ENGINE	7-3
ELECTRICAL.....	7-7
TIGHTENING TORQUES	7-8


GENERAL TORQUE SPECIFICATIONS	7-10
LUBRICATION POINTS AND TYPE OF LUBRICANTS.....	7-11
WIRE ROUTING DIAGRAM	7-12
UPPER SIDE VIEW.....	7-12
LEFT SIDE VIEW	7-16
RIGHT SIDE VIEW.....	7-18
REAR SIDE VIEW	7-22

GENERAL INFORMATION

MACHINE IDENTIFICATION

SERIAL NUMBER

The serial number is printed on the label “1” affixed to the position of the multi-purpose engine as shown in the illustration.



TIP

- The first four digits identify the model, and the remaining digits indicates the production number.
- Designs and specifications are subject to change without notice.

STARTING SERIAL NUMBER

Model	Code	Starting serial number
MX775VJ7L6	7U2J	7U2J-1000101-
MX775VJ7W6		7U2J-2000101-
MX775VJ7X6		7U2J-3000101-
MX800VJ7L6	7U1J	7U1J-1000101-
MX800VJ7W6		7U1J-2000101-
MX800VJ7X6		7U1J-3000101-
MX825VJ7L6	7UDJ	7UDJ-1000101-
MX825VJ7W6		7UDJ-2000101-
MX825VJ7X6		7UDJ-3000101-

DIMENSIONS


1

GENERAL INFORMATION

DIMENSIONS


TOP

mm (in)



MOUNTING BASE

mm (in)



*1: UNC: Unified coarse thread (Unit: in)

*2: PCD: Pitch Circle Diameter


DIMENSIONS

REAR

mm (in)


1

GENERAL INFORMATION



REAR (For models equipped with a muffler)

mm (in)




DIMENSIONS

1
GENERAL INFORMATION


RIGHT SIDE

mm (in)



RIGHT SIDE (For models equipped with a muffler)

mm (in)




IMPORTANT INFORMATION

PREPARATION FOR REMOVAL AND DISASSEMBLY

CAUTION ON SERVICE

Fire prevention


When servicing the engine, always keep the engine and yourself away from fire.



NOTES ON SERVICE

Correct tools

Be sure to use the correct special tool for the job to guard against damage.




Oil, grease and seals

Be sure to use genuine Yamaha oils, grease and sealers, or the equivalents.



Expendable parts


Always replace the gaskets, O-rings, cotter pins and cir-clips with new parts when servicing engine.



IMPORTANT INFORMATION

1

GENERAL INFORMATION




Tightening torque


Be sure to follow torque specifications. When tightening bolts, nuts or screws, start with the largest-diameter fastener and work from an inner position to an outer position in a crisscross pattern.

Notes on disassembly and assembly


- Parts should be cleaned in solvent and blown dry with compressed air after disassembly.



Solvent



- Contact surfaces of moving parts should be oiled when reassembled.
- Make sure that the parts, move smoothly after each section of the machine is assembled.



ALL REPLACEMENT PARTS


We recommend the use of genuine Yamaha parts for all replacements. Use oil and/or grease, recommended by Yamaha, for assembly and adjustment.

GASKETS, OIL SEALS, AND O-RINGS

1. All gaskets, seals, and O-rings should be replaced when an engine is overhauled. All gasket surfaces, oil seal lips, and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.

BEARINGS AND OIL SEALS

Install the bearing(s) “1” and oil seal(s) “2” with their manufacture’s marks or numbers facing outward. (In other words, the stamped letters must be on the side exposed to view.) When installing oil seal(s), apply a light coating of lightweight lithium base grease to the seal lip(s). Oil the bearings liberally when installing.



NOTICE

Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.


BASIC SERVICE INFORMATION

ELECTRICAL SYSTEM

Checking the electrical system


TIP


Before checking the electrical system, make sure that the battery voltage is at least 12 V.



NOTICE

Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end “a” of the coupler, taking care not to loosen or damage the leads.






Checking the connections

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:
 - Lead
 - Coupler
 - Connector


NOTICE

- When disconnecting a coupler, release the coupler lock, hold both sections of the coupler securely, and then disconnect the coupler.
 - There are many types of coupler locks; therefore, be sure to check the type of coupler lock before disconnecting the coupler.
-






NOTICE

When disconnecting a connector, do not pull the leads. Hold both sections of the connector securely, and then disconnect the connector.



2. Check:
 - Lead
 - Coupler
 - ConnectorMoisture → Dry with an air blower.
Rust/stains → Connect and disconnect several times.



BASIC SERVICE INFORMATION



- 3.** Connect:
- Lead
 - Coupler
 - Connector

TIP

- When connecting a coupler or connector, push both sections of the coupler or connector together until they are connected securely.
- Make sure all connections are tight.




- 4.** Check:

- Continuity
(with the digital circuit tester)

	Model 88 Multimeter with tachometer: YU-A1927
--	--

TIP


- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.



NOTICE

For waterproof couplers, never insert the tester leads directly into the coupler. When performing any checks using a waterproof coupler, use the specified test harness or a suitable commercially available test harness.

BASIC SERVICE INFORMATION




- 5.** Check:
- Resistance

	Model 88 Multimeter with tachometer: YU-A1927
---	--

TIP

The resistance values shown were obtained at the standard measuring temperature of 20 °C (68 °F). If the measuring temperature is not 20 °C (68 °F), the specified measuring conditions will be shown.

	Engine temperature sensor resistance: 9.0 kΩ–11.0 kΩ at 25 °C (77 °F)
---	--

















SPECIAL TOOLS AND TESTERS

SPECIAL TOOLS AND TESTERS

The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

1

GENERAL INFORMATION

<p>Valve spring compressor 90890-01253</p> 	<p>Ignition checker 90890-06754</p> 	<p>FI Diagnostic Tool 90890-03253</p> 	<p>Feeler gauge set YU-26900-9</p> 
<p>Oil filter wrench YM-01469</p> 	<p>Engine compression tester YU-33223 YU-33223</p> 	<p>Primary clutch holder YU-01235</p> 	<p>Rotor holding tool 90890-01235</p> 
<p>Heavy duty puller YU-33270-B</p> 	<p>Cylinder gauge Commercially obtainable</p> 	<p>Piston ring compressor YM-08037</p> 	<p>Dial indicator gauge YU-A8428</p> 
<p>Pressure/vacuum tester YB-35956-B</p> 	<p>Fuel pressure gauge YU-03153</p> 	<p>Fuel pressure adapter YM-03186</p> 	<p>Model 88 Multimeter with tachometer YU-A1927</p> 

MEMO

1
GENERAL INFORMATION

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable machine operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to machines already in service as well as new machines that are being prepared for sale. All service technicians should be familiar with this entire chapter.

MAINTENANCE INTERVALS CHART



Proper periodic maintenance is important. Especially important are the maintenance services related to emissions control. These controls not only function to ensure air filter but are also vital to proper engine operation and maximum performance.

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

	Daily	50 hrs	100 hrs	200 hrs	250 hrs	500 hrs	1000 hrs
Check spark plug			√				
Check muffler and spark arrester			√ (*1)				
Check oil level	√						
Change engine oil			√				
Change oil filter				√			
Clean fan case covers and cooling area				√			
Check and change fuel filter			√				
Check fuel line	√						
Clean oil cooler fins				√			
Check air filter element		√					
Replace air filter element					√		
Check air filter inner element					√		
Replace air filter inner element						√	
Check valve clearance							√ (*2)
Clean combustion chamber							√ (*2)
Idle speed							√ (*2)
Fitting/fastener							√ (*2)
Check leaks and anything operator notices such as noises or abnormal operation.	√						

*1 For models equipped with a Yamaha muffler.

*2 Items marked with an asterisk require special tools, data and technical skills, have a Yamaha dealer perform the service.



PERIODIC MAINTENANCE

SPARK PLUGS

⚠ WARNING


Check and adjust the areas around the cylinder head after the engine has cooled down completely.

1. Remove:
 - Spark plug caps “1”
 - Spark plugs

NOTICE

Before removing the spark plugs, use compressed air to clean the cylinder head covers to prevent dirt from falling into the engine.


2. Check:
 - Spark plug type
Not correct → Replace.

	Spark plug type: BPR6ES (NGK)
--	--

- Electrode “1”
Wear/damage → Replace.
- Insulator color “2”
Not normal → Replace.


3. Measure:
 - Spark plug gap “a”
Use a wire gauge or feeler gauge set.
Out of specification → Regap.
If necessary, clean the spark plugs with a spark plug cleaner.

	Feeler gauge set: YU-26900-9
---	---


	Spark plug gap: 0.7–0.8 mm (0.028–0.031 in)
---	--

TIP

Before installing the spark plugs, clean the gasket surface and plug surface.



4. Install:
 - Spark plugs

	Spark plug: 20 N·m (2.0 kgf·m, 14 lb·ft)
---	--

TIP

To prevent threads from being damaged, temporarily tighten “a” the spark plug before tightening it to the specified torque “b”.

MUFFLER

(For models equipped with a muffler)




WARNING

The engine and muffler will be very hot after the engine has been run.

Avoid touching the engine and muffler while they are still hot with any part of your body or clothing during check or repair.


1. Remove:
 - Spark arrester screw “1”




2. Remove:
 - Spark arrester “1”

TIP

Use a flathead screw driver to pry the spark arrester out from the muffler.






- 3.** Remove:
- Muffler
(Refer to “MUFFLER (For models equipped with a muffler)” on page 3-4)

- 4.** Decarbonize:
- Muffler
Tap on the muffler in the area shown in the illustration to loosen carbon buildup, and then shake it out from the end of the muffler.

NOTICE


Do not use a wire brush to clean, otherwise the noise damping material may come out, and the damping effect may be reduced.



- 5.** Decarbonize:
- Spark arrester

NOTICE

When cleaning with a wire brush, use it softly to avoid damage or scratch the spark arrester.



- 6.** Install:
- Muffler
(Refer to “MUFFLER (For models equipped with a muffler)” on page 3-4)
 - Spark arrester
 - Spark arrester screw

	Spark arrester screw: 3.5 N·m (0.35 kgf·m, 2.5 lb·ft)
---	--




TIP

Align the spark arrester lump “a” with the hole “b” in the muffler pipe.

ENGINE OIL LEAKAGE

- 1.** Place the multi-purpose engine on a level surface.

- Check the areas outside of the engine for oil leakage.
Oil leakage → Replace the gasket, oil seal, or O-ring.



ENGINE OIL LEVEL

- Remove:
 - Oil filler cap “1”
- Check:
 - Check that engine oil is at the specified level.



- Place the multi-purpose engine on a level surface.
- Warm up the engine for several minutes.
- Stop the engine.
- Remove the oil filler cap.
- Wipe the engine oil dipstick “1” clean, insert it back into the oil filler hole (without screwing it in), and then remove it again to check the oil level.
Add oil if necessary.

TIP _____
The engine oil should be between the minimum “a” and maximum “b” level marks.



- Install:
 - Oil filler cap

TIP _____
Check whether the oil warning light comes on by turning the main switch.


Oil warning light comes on → Add oil.
 Oil warning light does not come on → OK

REPLACING THE ENGINE OIL

! WARNING


Avoid draining the engine oil immediately after stopping the engine. The oil is hot and should be handled with care to avoid burns.

1. Warm up the engine for several minutes, and then stop the engine.
Place the oil pan under the engine.
2. Remove:
 - Oil filler cap
 - Oil drain bolt "1"
 - Oil drain bolt gasket "2"




3. Drain:
 - Engine oil
4. If the oil filter is also to be replaced, perform the following procedure.

- a. Remove the oil filter "1" with an oil filter wrench "2".



	Oil filter wrench: YM-01469
--	--


- b. Lubricate the O-ring "3" of the new oil filter with a thin coat of engine oil.




NOTICE

Make sure the O-ring "3" is positioned correctly in the groove of the oil filter.

PERIODIC MAINTENANCE




c. Tighten the new oil filter to specification with an oil filter wrench.

	Oil filter: 14 N·m (1.4 kgf·m, 10 lb·ft)
---	---





- 5.** Install:
- Oil drain bolt gasket "1" **New**
 - Oil drain bolt "2"




	Oil drain bolt: 27 N·m (2.7 kgf·m, 20 lb·ft)
---	---


- 6.** Fill:
- Engine oil
- Make sure to fill with the recommended engine oil from the oil filler hole "1" in the crankcase.



	Recommended engine oil: A YAMALUBE SAE 10W-30 Performance All Purpose, SAE 10W-30 or 10W-40 B SAE 5W-30 Recommended engine oil grade: API Service SE type or higher Engine oil quantity: 2.0 L (2.11 US qt, 1.76 Imp.qt)
--	---



- 7.** Check:
- Engine oil level
(Refer to "ENGINE OIL LEVEL" on page 2-5)



FUEL LEAKAGE

1. Check:
 - Leakage
Check at fuel pump, fuel hose, and throttle body.

NOTICE


Replace fuel hose every four years.

FUEL FILTER

! WARNING

Do not smoke, and keep away from open flames, sparks, or any other source of fire when handling or in the vicinity of fuel.


1. Remove:
 - Fuel filter



2. Check:
 - Fuel filter
Damage → Replace.
Dirt/clog → Clean.

TIP

Clean the fuel filter with clean gasoline, and then dry it thoroughly.




OIL COOLER

1. Check:
 - Oil cooler
 - Damage → Replace.
 - Dirt/clog → Clean.

AIR FILTER ELEMENT

NOTICE

Be sure not to run the engine without air filter element. Otherwise this can result in excessive piston and/or cylinder wear.



1. Remove:
 - Dust cap "1"
 - Air filter case cover "2"
 - Air filter element "3"
 - Inner element "4"
2. Check:
 - Air filter element
 - Inner element
 - Damage/dirty → Replace.
3. Install:
 - Inner element
 - Air filter element
 - Air filter case cover
 - Dust cap


ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

1. Remove:
 - Spark plug cap "1"
 - Spark plug "2"

NOTICE


Before removing the spark plug, use compressed air to clean the cylinder head cover to prevent dirt from falling into the engine.



PERIODIC MAINTENANCE

2

PERIODIC CHECKS AND ADJUSTMENTS



2. Remove:
 - Cylinder head cover “3”
 - Cylinder head cover gasket
3. Remove:
 - Fan case cover “1”
(Refer to “CASE AND FAN” on page 3-11)
 - Grass screen “2”
(Refer to “CASE AND FAN” on page 3-11)

4. Turn the crankshaft clockwise, and then set the piston at TDC (top-dead-center) on the compression stroke.

TIP _____
Check the piston position by inserting a screw driver into the spark plug hole.

5. Measure:
 - Valve clearance
(Between the rocker arm and adjusting pad)
Out of specification → Adjust to original set value at every 1000 hr.

TIP _____
Valve clearance must be measured when the engine has cooled down enough to be touched.

	Feeler gauge set: YU-26900-9
---	---



Valve clearance (cold):

Normal ENG operation range (between 1000 hr periodic maintenance):


Intake: 0.02–0.2 mm (0.0008–0.01 in)

Exhaust: 0.02–0.2 mm (0.0008–0.01 in)

Original set value (adjust at 1000 hr periodic maintenance):

Intake: 0.07–0.13 mm (0.003–0.005 in)

Exhaust: 0.07–0.13 mm (0.003–0.005 in)




- 6. Adjust:**
- Adjust to original set value

TIP

- When adjust valve clearance, record the measured reading of current.
- Measure the valve clearance in the following sequence.

Valve clearance measuring sequence

Cylinder #2 → #1




- a. Remove the rocker arm “1” and the adjusting pad “2”.

(Refer to “CYLINDER HEAD COVERS, CYLINDER HEADS” on page 3-20)

TIP

- Pay attention so that the push rod does not fall into the cylinder head.
- Make a note of the position of each adjusting pad “3” so that they can be installed in the correct place.




- b. Calculate the difference between the specified valve clearance and the measured valve clearance.

Example:

Specified valve clearance = 0.07–0.13 mm (0.003–0.005 in)

Measured valve clearance = 0.18 mm (0.007 in)

0.18 mm (0.007 in)–0.13 mm (0.005 in) = 0.05 mm (0.002 in)



c. Check the thickness of the current adjusting pad.

TIP

The thickness of each adjusting pad is indicated in 1/100 mm units “a” and inscribed on the side.

Example:

If the adjusting pad is marked “180”, the pad thickness is 1.80 mm (0.071 in).

d. Calculate the sum of the values obtained in steps (b) and (c) to determine the required adjusting pad thickness and the adjusting pad number.

Example:

1.80 mm (0.071 in) + 0.05 mm (0.002 in) = 1.85 mm (0.073 in)

The adjusting pad number is 185.

e. Round off the adjusting pad number according to the following table, and then select the suitable adjusting pad.

Last digit	Rounded value
0,2	0
5	5
8	10

TIP

Refer to the following table for the available adjusting pads.

Adjusting pad range	Nos. 180–300
Adjusting pad thickness	1.80–3.00 mm (0.07086–0.11811 in)
Available adjusting pads	0.050 mm (0.002 in) increments

Example:

Adjusting pad number = 188


Rounded value = 200


New adjusting pad number = 200

f. Install the new adjusting pad “4”.

TIP

Lubricate the adjusting pad with engine oil.





- g. Install the rocker arm “5”.
(Refer to “CYLINDER HEAD COVERS, CYLINDER HEADS” on page 3-20)

	Rocker arm shaft bolt: 4.0 N·m (0.40 kgf·m, 2.9 lb·ft)
---	---

TIP

- Lubricate the rocker arm with engine oil.
- Turn the crankshaft clockwise several full turns to seat the parts.


- h. Measure the valve clearance again.
- i. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



- 7.** Install:
 - Cylinder head cover gasket **New**
 - Cylinder head cover
 - Cylinder head cover bolts

	Cylinder head cover bolt: 11 N·m (1.1 kgf·m, 8.0 lb·ft)
---	--


- Spark plug

	Spark plug: 20 N·m (2.0 kgf·m, 14 lb·ft)
---	---

- Spark plug cap

CYLINDER HEADS DECARBONIZATION

- 1.** Remove:
 - Cylinder heads
(Refer to “CYLINDER HEAD COVERS, CYLINDER HEADS” on page 3-20)
- 2.** Eliminate:
 - Carbon deposits
(Refer to “CHECKING THE CYLINDER HEADS” on page 3-24)
- 3.** Install:
 - Cylinder heads
(Refer to “INSTALLING THE CYLINDER HEAD ASSEMBLY” on page 3-25)



ENGINE SPEED

1. Warm up the engine for several minutes.
2. Connect:
 - FI Diagnostic Tool “1”


	FI Diagnostic Tool: 90890-03253
--	--

3. Measure:
 - High engine speed (with no load)
 Out of specification → Adjust.

	High engine speed (with no load): 3550–3600 r/min
--	--



- a. Move the throttle lever “1” to the high engine speed position “a”.



- b. Check the high engine speed.




4. Measure:
 - Low engine speed (with no load)
 Out of specification → Adjust.

	Low engine speed (with no load): 1450–1550 r/min
--	---



- a. Move the throttle lever “1” to the low engine speed position “a”.




b. Check the low engine speed.



ADJUSTING THE ENGINE SPEED

- 1.** Warm up the engine for several minutes.
- 2.** Connect:
 - FI Diagnostic Tool “1”




	FI Diagnostic Tool: 90890-03253
---	--

- 3.** Adjust:
 - High engine speed




a. Move the throttle lever “1” to the high engine speed position “a”.



b. Turn the throttle stop screw “2” in direction “b” or “c” until the high engine speed is obtained.

Direction “b” High engine speed is increased. Direction “c” High engine speed is decreased.
--

	High engine speed (with no load): 3550–3600 r/min
---	--




- 4.** Adjust:
 - Low engine speed

PERIODIC MAINTENANCE

2

PERIODIC CHECKS AND ADJUSTMENTS



a. Move the throttle lever “1” to the low engine speed position “a”.

b. Turn the screw “3” in direction “c” or “d” until obtain adequate low engine speed.

Direction “c”
Low engine speed is decreased.
Direction “d”
Low engine speed is increased.


	Low engine speed (with no load): 1450–1550 r/min
--	---

LOW ENGINE SPEED (Replace the throttle body)

TIP

When replace throttle body, follow the procedure below. Adjust low engine speed with throttle stop screw “1” in direction “a” or “b”.

1. Turn the throttle stop screw “1” (throttle body) in direction “a” or “b” until the low engine speed is obtained.



Direction “a”
Low engine speed is decreased.
Direction “b”
Low engine speed is increased.

	Low engine speed (with no load): 1450–1550 r/min
--	---

FITTINGS AND FASTENERS

1. Check:

- All fittings and fasteners
Looseness → Tighten.
Rough movement → Replace the defective part(s).
Damage/pitting → Replace.

ENGINE

ENGINE INSPECTION

MEASURING THE COMPRESSION PRESSURE

The following procedure applies to all of the cylinders.


TIP

Measure the compression pressure after checking and adjusting the valve clearance.

1. Warm up the engine for several minutes.
2. Remove:
 - Spark plug cap
 - Spark plug

NOTICE


Before removing the spark plug, use compressed air to clean the cylinder head cover to prevent dirt from falling into the engine.



3. Connect:
 - Engine compression tester "1"
 - Extension "2"

	Engine compression tester: YU-33223
---	---

4. Measure:
 - Compression pressureOpen the throttle and crank the engine until the needle stop rising on the engine compression tester.
Out of specification → Refer to steps (a) and (b).


	Standard compression pressure: 1.31–1.45 MPa (13.4–14.8 kg/cm ² , 190–210 psi) Limit: 1.03 MPa (10.3 kg/cm ² , 150 psi)
---	--

WARNING

To prevent sparking the plugs, remove all ignition coil couplers and fuel injector couplers before cranking the engine.

AIR FILTER


AIR FILTER



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the air filter		Remove the parts in the order listed.
1	Dust cap	1	
2	Air filter case cover	1	
3	Air filter element	1	
4	Inner element	1	
5	Air filter cover 1	1	
6	Air filter case stay	1	
7	Air filter case	1	
8	Joint 2	1	

MUFFLER (For models equipped with a muffler)


MUFFLER (For models equipped with a muffler)



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the muffer		Remove the parts in the order listed.
1	Muffer	1	
2	Spark arrester	1	
3	Gasket	2	
4	O ₂ sensor	1	

OIL COOLER

OIL COOLER



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the oil cooler		Remove the parts in the order listed.
	Engine oil		Drain. Refer to "REPLACING THE ENGINE OIL" on page 2-6.
1	Oil cooler	1	
2	Oil hose 1	1	
3	Oil hose 2	1	
4	Oil filter	1	
5	Adapter union bolt	1	
6	Adapter	1	
7	Oil seal	1	

OIL COOLER

REMOVING THE OIL COOLER

1. Remove:
 - Hose clamp (Clic-R) "1"

TIP

- Remove the hose clamp using the hose clamp pliers "2".
- When removing the hose clamp, make sure that the thick tip "a" of the hose clamp pliers is directed as shown in the illustration.

A. Hose clamp pliers

2. Remove:
 - Oil hose 1
 - Oil hose 2
 - Oil cooler


CHECKING THE OIL COOLER


1. Check:
 - Oil cooler "1"
 - Oil hose 1 "2"
 - Oil hose 2 "3"
 - Adapter "4"

Damage → Replace.
Dirt/clog → Clean.




INSTALLING THE OIL COOLER

1. Clean:
 - Mating surfaces of the adapter and the crankcase cover 2
(with a cloth dampened with lacquer thinner)
2. Install:
 - Oil seal "1" **New**
 - Adapter "2"
 - Adapter union bolt "3"



	Adapter union bolt: 62 N·m (6.2 kgf·m, 45 lb·ft)
---	--



A




OIL COOLER



1 **New**

2

A



TIP

- Make sure the oil seal is positioned properly.
- Align the projection “a” on the adapter with the hole “b” in the crankcase cover 2.

3. Install:

- Oil filter
- Oil hose 2
- Oil hose 1
- Hose clamp (Clic-R) “1” **New**

TIP

- Install the hose clamp using the hose clamp pliers “2”.
- When installing the hose clamp, make sure that the thin tip “a” of the hose clamp pliers is directed as shown in the illustration.

A. Hose clamp pliers

4. Install:

- Oil cooler
- Oil cooler bolts




Oil cooler bolt:

9 N·m (0.9 kgf·m, 6.5 lb·ft)

ECU, RECTIFIER/REGULATOR, AND FUSES

3
ENGINE

ECU, RECTIFIER/REGULATOR, AND FUSES




Order	Job/Parts to remove	Q'ty	Remarks
	Removing the ECU, rectifier/regulator, and fuses		Remove the parts in the order listed.
1	ECU coupler	2	Disconnect.
2	Earth terminal	1	
3	ECU	1	
4	Engine hunger	1	For maintenance.
5	Rectifier/regulator lead connector	4	Disconnect.
6	Rectifier/regulator	1	
7	Fuse holder bracket	1	
8	Fuse	1	30 A
9	Fuse	2	10 A

INSTALLING THE FUSES

1. Install:
 - 30 A fuse "1"
 - 10 A fuses "2"

NOTICE


For the 30 A fuse "1", there is identification red tape "a" on the wire harness.



IGNITION COILS

IGNITION COILS


3
ENGINE



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the ignition coils		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU and rectifier/regulator		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	Low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
	Fan case		Refer to "CASE AND FAN" on page 3-11.
1	Ignition coil #1 lead coupler	1	Disconnect.
2	Ignition coil #2 lead coupler	1	Disconnect.
3	Ignition coil #1	1	
4	Ignition coil #2	1	
5	Spark plug	2	

CASE AND FAN


CASE AND FAN



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the case and fan		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU and rectifier/regulator		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	Low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
1	Oil filler cap	1	
2	Oil filler pipe	1	
3	O-ring	1	
4	Fan case cover	1	
5	Grass screen	1	
6	Fan case	1	
7	Fan	1	

REMOVING THE CASE AND FAN

1. Remove:
 - Air filter case
(Refer to “AIR FILTER” on page 3-3)
2. Remove:
 - ECU and rectifier/regulator
(Refer to “ECU, RECTIFIER/REGULATOR, AND FUSES” on page 3-8)
3. Remove:
 - Low-pressure fuel pump
(Refer to “FUEL PUMPS” on page 4-1)
4. Remove:
 - Oil cooler
(Refer to “OIL COOLER” on page 3-5)
5. Remove:
 - Oil filler cap
 - Oil filler pipe
6. Remove:
 - Fan case cover “1”
 - Grass screen “2”
 - Fan case “3”
 - Fan “4”




NOTICE

Because there is a risk of damage, remove the grass screen “2” and fan case “3” in this order.

CHECKING THE CASE AND FAN

1. Check:
 - Fan case cover “1”
 - Grass screen “2”
 - Fan case “3”
 - Fan “4”
 Damage → Replace.
 Dirt/clog → Clean.




INSTALLING THE CASE AND FAN


1. Install:
 - Fan “1”
 - Fan bolts

	Fan bolt: 10 N·m (1.0 kgf·m, 7.2 lb·ft)
---	--


- Fan case “2”
- Fan case bolts


	Fan case bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	--

- Grass screen “3”
- Grass screen bolts

	Grass screen bolt: 10 N·m (1.0 kgf·m, 7.2 lb·ft)
---	---

- Fan case cover “4”
- Fan case cover bolts


	Fan case cover bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	--



CASE AND FAN

3

ENGINE



TIP

Insert the tab “a” of the fan case cover “4” into the hole “b” of the fan case “2” first and then install.

2. Install:

- Oil filler pipe
- Oil filler pipe bolt




Oil filler pipe bolt:

7 N·m (0.7 kgf·m, 5.1 lb·ft)

- Oil filler cap

FLYWHEEL AND STATOR COIL ASSEMBLY

FLYWHEEL AND STATOR COIL ASSEMBLY



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the flywheel and stator coil assembly		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU and rectifier/regulator		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	Low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
	Fan case		Refer to "CASE AND FAN" on page 3-11.
1	Crankshaft position sensor lead coupler	1	Disconnect.
2	Crankshaft position sensor	1	
3	Flywheel	1	
4	Woodruff key	1	
5	Stator coil assembly	1	



FLYWHEEL AND STATOR COIL ASSEMBLY

3

ENGINE

REMOVING THE FLYWHEEL AND STATOR COIL ASSEMBLY

1. Remove:
 - Air filter case
(Refer to “AIR FILTER” on page 3-3)
2. Remove:
 - ECU and rectifier/regulator
(Refer to “ECU, RECTIFIER/REGULATOR, AND FUSES” on page 3-8)
3. Remove:
 - Low-pressure fuel pump
(Refer to “FUEL PUMPS” on page 4-1)
4. Remove:
 - Oil cooler
(Refer to “OIL COOLER” on page 3-5)
5. Remove:
 - Fan case cover
 - Grass screen
 - Fan case
 - Fan
(Refer to “CASE AND FAN” on page 3-11)
6. Remove:
 - Crankshaft position sensor “1”
7. Remove:
 - Flywheel nut “1”
 - Washer “2”



TIP

Attach the primary clutch holder “3” to hold the flywheel.




Primary clutch holder:

YU-01235

Rotor holding tool:

90890-01235


FLYWHEEL AND STATOR COIL ASSEMBLY



- 8.** Remove:
- Flywheel “1”
 - Woodruff key

TIP


- Remove the flywheel “1” using the heavy duty puller “2”.
- Fully tighten the tool holding bolts, making sure the tool body is parallel with the flywheel. If necessary, one bolt may be backed out slightly to level the tool body.

	Heavy duty puller: YU-33270-B
---	--

- 9.** Remove:
- Stator coil assembly


CHECKING THE FLYWHEEL AND STATOR COIL ASSEMBLY

- 1.** Check:
- Flywheel “1”
 - Stator coil assembly “2”
- Damage → Replace.



INSTALLING THE FLYWHEEL AND STATOR COIL ASSEMBLY

- 1.** Install:
- Stator coil assembly
 - Stator coil assembly bolts


	Stator coil assembly bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	--

- 2.** Install:
- Woodruff key
 - Flywheel

FLYWHEEL AND STATOR COIL ASSEMBLY

3

ENGINE



- 3.** Install:
- Washer “1”
 - Flywheel nut “2”



Flywheel nut:
180 N·m (18 kgf·m, 130 lb·ft)

TIP

Tighten the flywheel nut “2” using the primary clutch holder “3” to hold the flywheel.



Primary clutch holder:
YU-01235
Rotor holding tool:
90890-01235

- 4.** Install:
- Crankshaft position sensor
 - Crankshaft position sensor bolts
(Refer to “INSTALLING THE CRANKSHAFT POSITION SENSOR” on page 3-19)



Crankshaft position sensor bolt:
7 N·m (0.7 kgf·m, 5.1 lb·ft)

- 5.** Install:
- Fan
 - Fan case
 - Grass screen
 - Fan case cover
(Refer to “CASE AND FAN” on page 3-11)

- 6.** Install:
- Low-pressure fuel pump
(Refer to “FUEL PUMPS” on page 4-1)


- 7.** Install:
- ECU and rectifier/regulator
(Refer to “ECU, RECTIFIER/REGULATOR, AND FUSES” on page 3-8)

- 8.** Install:
- Air filter case
(Refer to “AIR FILTER” on page 3-3)

FLYWHEEL AND STATOR COIL ASSEMBLY


INSTALLING THE CRANKSHAFT POSITION SENSOR

1. Install:
 - Crankshaft position sensor
 - Crankshaft position sensor bolts

	Crankshaft position sensor bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	---

2. Measure:
 - Crankshaft position sensor air gap
 Out of specification → Adjust.

	Feeler gauge set: YU-26900-9
---	--


	Crankshaft position sensor air gap: 0.5–1.5 mm (0.02–0.06 in)
---	---

3. Adjust:
 - Crankshaft position sensor air gap






- a. Loosen the crankshaft position sensor bolts “1”.
- b. Adjust the crankshaft position sensor air gap.

	Feeler gauge set: YU-26900-9
---	--

	Crankshaft position sensor air gap: 0.5–1.5 mm (0.02–0.06 in)
---	---

- c. Tighten the crankshaft position sensor bolts “1”.

	Crankshaft position sensor bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	---




CYLINDER HEAD COVERS, CYLINDER HEADS

CYLINDER HEAD COVERS, CYLINDER HEADS

CYLINDER HEAD #1


3
ENGINE



⚔	1st	12 N·m (1.2 kgf·m, 8.7 lb·ft)
	2nd	50 N·m (5.0 kgf·m, 36 lb·ft)

Order	Job/Parts to remove	Q'ty	Remarks
	Removing the cylinder head covers, and cylinder heads		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU, rectifier/regulator and fuse		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	High and low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
	Fan case		Refer to "CASE AND FAN" on page 3-11.
	Flywheel and stator coil assembly		Refer to "FLYWHEEL AND STATOR COIL ASSEMBLY" on page 3-15.
	Throttle body assembly		Refer to "THROTTLE BODY ASSEMBLY" on page 4-6.
	Intake manifold		Refer to "FUEL INJECTORS AND INTAKE MANIFOLD" on page 4-9.
	Starter motor assembly		Refer to "REMOVING THE STARTER MOTOR" on page 5-37.

CYLINDER HEAD COVERS, CYLINDER HEADS




	1st	12 N·m (1.2 kgf·m, 8.7 lb·ft)
	2nd	50 N·m (5.0 kgf·m, 36 lb·ft)

Order	Job/Parts to remove	Q'ty	Remarks
1	Cylinder air shroud	1	
2	Cylinder head cover	1	
3	Cylinder head cover gasket	1	
4	Rocker arm shaft	1	Intake
5	Rocker arm shaft	1	Exhaust
6	Rocker arm	1	Intake
7	Rocker arm	1	Exhaust
8	Adjusting pad	3	
9	Push rod	2	
10	Cylinder head assembly #1	1	
11	Cylinder head gasket	1	
12	Dowel pin	2	

CYLINDER HEAD COVERS, CYLINDER HEADS


CYLINDER HEAD #2

ENGINE 3




Order	Job/Parts to remove	Q'ty	Remarks
	Removing the cylinder head covers, and cylinder heads		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU, rectifier/regulator and fuse		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	High and low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
	Fan case		Refer to "CASE AND FAN" on page 3-11.
	Flywheel and stator coil assembly		Refer to "FLYWHEEL AND STATOR COIL ASSEMBLY" on page 3-15.
	Throttle body assembly		Refer to "THROTTLE BODY ASSEMBLY" on page 4-6.
	Intake manifold		Refer to "FUEL INJECTORS AND INTAKE MANIFOLD" on page 4-9.
	Starter motor assembly		Refer to "REMOVING THE STARTER MOTOR" on page 5-37.

CYLINDER HEAD COVERS, CYLINDER HEADS



Order	Job/Parts to remove	Q'ty	Remarks
1	Engine hunger	1	For maintenance.
2	Cylinder air shroud	1	
3	Cylinder head cover	1	
4	Cylinder head cover gasket	1	
5	Rocker arm shaft	1	Intake
6	Rocker arm shaft	1	Exhaust
7	Rocker arm	1	Intake
8	Rocker arm	1	Exhaust
9	Adjusting pad	3	
10	Push rod	2	
11	Cylinder head assembly #2	1	
12	Cylinder head gasket	1	
13	Dowel pin	2	



CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS


The following procedure applies to all of the rocker arms and rocker arm shafts.

1. Check:
 - Rocker arm “1”
 - Rocker arm shaft “2”Wear/damage/cracks → Replace.

CHECKING THE PUSH RODS

The following procedure applies to all of the push rods.

1. Check:
 - Push rod runout



	Runout limit: 0.3 mm (0.0118 in)
--	---

Out of specifications → Replace.

REMOVING THE CYLINDER HEADS

The following procedure applies to all of the cylinder heads.

1. Remove:
 - Cylinder head

TIP


Set the piston at TDC (top-dead-center) on the compression stroke.

(Refer to “ADJUSTING THE VALVE CLEARANCE” on page 2-9.)

CHECKING THE CYLINDER HEADS

The following procedure applies to all of the cylinder heads.


CYLINDER HEAD COVERS, CYLINDER HEADS



- 1.** Check:
 - Cylinder head combustion chamber
Check the combustion chamber for carbon deposits.
 - Any carbon deposits → Eliminate.

TIP

Be sure not to damage the sealing surface of the cylinder head.



- 2.** Check:
 - Cylinder head
Cracks/damage around the hole of spark plug → Replace.
- 3.** Measure:
 - Cylinder head warpage

TIP

Measure the warpage on the contact surface of the cylinder head at six points using the straight edge and feeler gauge set.

	Warpage limit: 0.05 mm (0.002 in)
--	--


Out of specifications → Resurface or replace.

INSTALLING THE CYLINDER HEAD ASSEMBLY

- 1.** Install:
 - Cylinder head assembly #1
 - Cylinder head bolts “1” to “5”.

TIP

Tighten the bolts to the specified torque in two steps and in order from “1” to “5”.




	Cylinder head bolt: 1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft) 2nd: 50 N·m (5.0 kgf·m, 36 lb·ft)
--	---

- 2.** Install:
 - Cylinder head assembly #2
 - Cylinder head bolts “1” to “5”.

TIP

Tighten the bolts to the specified torque in two steps and in order from “1” to “5”.



CYLINDER HEAD COVERS, CYLINDER HEADS




Cylinder head bolt:

1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft)

2nd: 50 N·m (5.0 kgf·m, 36 lb·ft)

VALVES


VALVES



3

ENGINE

Order	Job/Parts to remove	Q'ty	Remarks
	Removing the valves		Remove the parts in the order listed. The following procedure applies to both cylinders.
	Cylinder head assembly		Refer to "CYLINDER HEAD COVERS, CYLINDER HEADS" on page 3-20.
1	Valve cotter	3	
2	Valve spring retainers	3	
3	Intake valve spring	2	
4	Exhaust valve spring	1	
5	Intake valve	2	
6	Exhaust valve	1	
7	Valve stem seal	3	
8	Valve spring seat	3	



REMOVING THE VALVES AND VALVE SPRINGS

The following procedure applies to all of the valves, valve springs and related components.

1. Remove:
 - Valve cotter “1”
 - Valve spring retainer “2”
 - Valve spring “3”
 - Valve stem seal “4”
 - Valve spring seat “5”
 - Valve “6”

Remove the parts using the valve spring compressor “7”.

NOTICE

Do not compress the valve spring more than necessary.




Valve spring compressor:
90890-01253

CHECKING THE VALVES AND VALVE SPRINGS

The following procedure applies to all of the valves, valve springs and related components.

1. Measure:
 - Valve stem length “a”
 - Valve head diameter “b”




Valve stem length (Intake):
88.8 mm (3.4961 in)
Valve stem length (Exhaust):
89.8 mm (3.5354 in)
Valve head diameter (Intake):
27.9–28.1 mm (1.0984–1.1063 in)
Valve head diameter (Exhaust):
34.9–35.1 mm (1.3740–1.3819 in)


Out of specifications → Replace.

TIP

Intake and exhaust springs are different. Do not mix.





- 2.** Measure:
- Valve stem diameter “a”

	Valve stem diameter (Intake): 5.948–5.963 mm (0.2342–0.2348 in)
	Valve stem diameter (Exhaust): 5.940–5.955 mm (0.2339–0.2344 in)
	Limit (Intake): 5.918 mm (0.2330 in)
	Limit (Exhaust): 5.910 mm (0.2327 in)

Out of specifications → Replace.

- 3.** Measure:
- Valve stem runout




	Valve stem runout limit: 0.01 mm (0.0004 in)
---	--


Out of specifications → Replace.

TIP

The value is half of that indicated on the dial indicator gauge.




- 4.** Measure:
- Valve spring free length “a”


	Valve spring free length (Intake): 37.1 mm (1.4606 in)
	Valve spring free length (Exhaust): 35.6 mm (1.4016 in)
	Limit (Intake): 35.25 mm (1.3878 in)
	Limit (Exhaust): 33.82 mm (1.3315 in)



Out of specifications → Replace.

- 5.** Measure:
- Compressed valve spring force “a”
Out of specification → Replace.


b. Installed length



	Installed compression spring force (Intake): 67.7 N (6.90 kgf, 15.2 lbf)
	Installed compression spring force (Exhaust): 118.1 N (12.0 kgf, 26.5 lbf)
	Installed length (Intake): 29.3 mm (1.1535 in)
	Installed length (Exhaust): 29.0 mm (1.1417 in)



- 6.** Measure:
- Valve spring tilt “a”

	Tilt limit:
	2.0 mm (0.0787 in)


Out of specifications → Replace.

- 7.** Check:
- Valve spring contact surface “a”
More than 2/3 of the contact surface does not contact → Replace.

CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.


- 1.** Remove carbon deposits from the valve face and valve seat.
- 2.** Apply a small amount of coarse mechanic’s blue layout fluid to the valve face “a”.



- 3.** Insert the valve into the valve guide and use a valve lapper to contact the valve face with the valve seat.

TIP

Do not rotate the valve while the valve face is contacting the valve seat.



4. Measure:

- Valve face contact width “a”
Make sure that the contact width along the entire valve face is within specifications.




Valve face contact width (Intake):
0.9–1.1 mm (0.0354–0.0433 in)
Valve face contact width (Exhaust):
0.9–1.1 mm (0.0354–0.0433 in)
Limit (Intake):
1.6 mm (0.063 in)
Limit (Exhaust):
1.6 mm (0.063 in)

Out of specification/rough/eccentric wear → Replace.

5. Measure:

- Valve seat contact width “a”
Make sure that the contact width along the entire valve seat is within specifications.




Valve seat contact width (Intake):
0.9–1.1 mm (0.0354–0.0433 in)
Valve seat contact width (Exhaust):
0.9–1.1 mm (0.0354–0.0433 in)
Limit (Intake):
1.6 mm (0.063 in)
Limit (Exhaust):
1.6 mm (0.063 in)

Out of specification/rough/eccentric wear → Replace.

VALVE LAPPING

- 1.** Apply a coarse lapping compound evenly on the valve face. Lap the valve by tapping and rotating the valve lapper clockwise and counterclockwise.



- 2.** Clean off all of the lapping compound from the valve face and valve seat. Apply fine lapping compound on the valve face and lap the valve as described in step 1.

- Once the contacting surface of the valve face is polished and becomes shiny, apply mechanic's blue layout fluid to make sure that there are traces of even contact in the center of the valve face.

NOTICE

Do not let the lapping compound enter the gap between the valve stem and the valve guide.

TIP

After every lapping procedure, clean off the compound from the valve face and valve seat.


INSTALLING THE VALVES AND VALVE SPRINGS

The following procedure applies to all of the valves, valve springs and related components.

- Install:

- Valve "1"
- Valve spring seat "2"
- Valve stem seal "3" **New**
- Valve spring "4"
- Valve spring retainer "5"
- Valve cotter "6" **New**


Use the valve spring compressor "7" to install the parts.



Valve spring compressor:
90890-01253


NOTICE

- Do not compress the spring more than necessary.
- Surface "a" with the rounded edges of the valve cotter must face downward (to the valve spring retainer side) when installing it on top of the valve spring retainer. If surface "b" of the opposite side is facing downward when the valve cotter is installed, it could result in the premature wear of the valve cotter.




OIL PUMP

OIL PUMP



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the oil pump		Remove the parts in the order listed.
	Cylinder head assembly		Refer to "CYLINDER HEAD COVERS, CYLINDER HEADS" on page 3-20.
1	Collar	1	
2	Crankcase cover 2	1	
3	Dowel pin	2	
4	Relief valve	1	
5	Oil pump cover	1	
6	Oil strainer cover	1	
7	Oil strainer	1	
8	Inner rotor	1	
9	Outer rotor	1	
10	Oil seal	1	
11	Oil pressure switch	1	



DISASSEMBLING THE OIL PUMP


1. Remove:
 - Crankcase cover 2
2. Remove:
 - Relief valve "1"
3. Remove:
 - Oil pump cover "1"
4. Remove:
 - Oil strainer cover "1"
 - Oil strainer "2"
 - Inner rotor "3"
 - Outer rotor "4"


CHECKING THE OIL PUMP

1. Check:
 - Inner rotor "1"
 - Outer rotor "2"


Cracks/damage/wear → Replace the defective part(s).
2. Check:
 - Oil strainer "1"
 - Oil strainer cover "2"

Damage → Replace.
Contaminants → Clean with solvent.






- 3.** Measure:
 - Inner-rotor-to-outer-rotor-tip clearance “a” and “b”
Out of specification → Replace the defective part(s).


	Inner-rotor-to-outer-rotor-tip clearance “a”: 0.0 mm (0.0 in) Inner-rotor-to-outer-rotor-tip clearance “b”: 0.19–0.35 mm (0.008–0.013 in)
---	--

- 4.** Check:
 - Oil pump operation
Rough movement → Replace the defective part(s).

CHECKING THE RELIEF VALVE


- 1.** Check:
 - Relief valve
Damage/wear/seized → Replace.



	Relief valve operating pressure (reference data): 342–538 kPa (3.42–5.38 kgf/cm ² , 49.59–78.01psi)
---	--


CHECKING THE CRANKCASE COVER 2


- 1.** Check:
 - Crankcase cover 2
Damage → Replace.



INSTALLING THE OIL PRESSURE SWITCH

- 1.** Check:
 - Oil pressure switch
Damage → Replace.
- 2.** Install:
 - Oil pressure switch “1”




	Oil pressure switch: 8 N·m (0.8 kgf·m, 5.8 lb·ft)
---	---

TIP Engage the two threads of the oil pressure switch screw

with the crankcase cover 2, apply LOCTITE®, and tighten to the specified torque.

ASSEMBLING THE OIL PUMP



1. Lubricate:
 - Inner rotor
 - Outer rotor

	Recommended lubricant: Engine oil
---	--


2. Install:
 - Outer rotor “1”
 - Inner rotor “2”
 - Oil strainer “3”
 - Oil strainer cover “4”


TIP

Face portion “a” of the oil strainer cover downward as shown in the illustration, and install it.




3. Install:
 - Oil pump cover “1”
 - Oil pump cover bolts

	Oil pump cover bolt: 10 N·m (1.0 kgf·m, 7.2 lb·ft)
---	---




4. Install:
 - Relief valve “1”

	Relief valve: 30 N·m (3.0 kgf·m, 22 lb·ft)
---	---

INSTALLING THE CRANKCASE COVER 2


1. Clean:
 - Mating surfaces of the crankcase and the crankcase cover 2
(with a cloth dampened with lacquer thinner)
2. Apply:
 - Sealant
(onto the crankcase cover 2 mating surfaces)



	Three bond No.1217G®
--	-----------------------------


3. Install:
 - Crankcase cover 2

TIP _____
Align the inner rotor “a” of the oil pump with the flat portion “b” of the crankshaft and install.



4. Install:
 - Crankcase cover 2 bolts “1” to “11”

TIP _____
Tighten the bolts to the specified torque in two steps and in order from “1” to “11”.




	Crankcase cover 2 bolt: 1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft) 2nd: 30 N·m (3.0 kgf·m, 22 lb·ft)
--	---

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT


CRANKCASE

ENGINE 3



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the crankcase		Remove the parts in the order listed.
	Cylinder head assembly		Refer to "CYLINDER HEAD COVERS, CYLINDER HEADS" on page 3-20.
1	Crankcase cover 1	1	
2	Dowel pin	2	
3	Bearing	1	
4	Bearing	1	
5	Clip	2	
6	Governor fork	1	
7	Flyweight shaft assembly	1	
8	Oil seal	1	
9	Cover 2	1	
10	Gasket	1	
11	Scroll air shroud	1	

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT




Order	Job/Parts to remove	Q'ty	Remarks
12	Cover 1	1	
13	Dowel pin	2	
14	Reed valve	1	
15	Engine temperature sensor	1	
16	Oil seal	1	

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT

3

ENGINE


PISTONS, CAMSHAFT, AND CRANKSHAFT



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the pistons, camshaft, and crankshaft		Remove the parts in the order listed.
1	Camshaft	1	
2	Valve lifter	4	
3	Connecting rod cap	2	
4	Crankshaft	1	
5	Connecting rod	2	
6	Piston pin circlip	4	
7	Piston pin	2	
8	Piston	2	
9	Top ring	2	
10	2nd ring	2	
11	Oil ring	2	

REMOVING THE FLYWEIGHT SHAFT ASSEMBLY AND GOVERNOR FORK

1. Remove:
 - Crankcase cover 1
 - Governor assembly
2. Remove:
 - Clips "1"
 - Governor fork "2"
 - Washers "3"




3. Remove:
 - Flyweight shaft assembly "1"
 - Washer "2"

TIP

Remove the flyweight shaft assembly by tapping the weight shaft from outside of the crankcase cover 1.


DISASSEMBLING THE FLYWEIGHT SHAFT ASSEMBLY


1. Remove:
 - Flyweight shafts "1"
 - Weights "2"
 - Collar "3"
 - Washer "4"
 - Circlip "5"
 - Weight shaft "6"



CHECKING THE FLYWEIGHT SHAFT ASSEMBLY


1. Check:
 - Flyweight shaft assembly move smoothly
Rough movement → Replace.






2. Check:
 - Weight
 - Flyweight shaft
 - Collar
 - Washer
 - Weight shaft
 Wear/damage → Replace.

ASSEMBLING THE FLYWEIGHT SHAFT ASSEMBLY




1. Install:
 - Weight shaft "1"
 - Circlip "2" **New**
 - Washer "3"
 - Collar "4"
 - Weights "5"
 - Flyweight shafts "6"

INSTALLING THE FLYWEIGHT SHAFT ASSEMBLY AND GOVERNOR FORK



1. Install:
 - Washer "1"
 - Flyweight shaft assembly "2"



2. Install:
 - Washers "1"
 - Governor fork "2"
 - Clips "3"

3. Install:
 - Governor assembly
 - Crankcase cover 1
(Refer to "INSTALLING THE CRANKCASE COVER 1" on page 3-47)

4. Adjust:
 - Governor

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT

(Refer to “INSTALLING THE THROTTLE BODY ASSEMBLY” on page 4-7)



REMOVING THE CAMSHAFT AND VALVE LIFTERS

The following procedure applies to all of the camshaft and valve lifters.

1. Remove:
 - Camshaft “1”

TIP

Remove the camshaft when the camshaft gear mark “a” and the crankshaft gear mark “b” are aligned.




2. Remove:
 - Valve lifter “1” (Intake)
 - Valve lifter “2” (Exhaust)

NOTICE


Mark the valve lifters so as not to confuse them during reassembly.

CHECKING THE CAMSHAFT

1. Check:
 - Camshaft
Crack/damage/wear → Replace.



PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT





- 2.** Check:
- Camshaft lobe dimensions “a” and “b”

	Camshaft lobe dimensions
	Lobe height “a” (Intake): 32.885 mm (1.2947 in)
	Limit: 32.785 mm (1.2907 in)
	Lobe height “a” (Exhaust): 33.957 mm (1.3369 in)
	Limit: 33.857 mm (1.3330 in)
	Base circle diameter “b” (Intake): 26.000 mm (1.0236 in)
	Limit: 25.900 mm (1.0197 in)
	Base circle diameter “b” (Exhaust): 26.000 mm (1.0236 in)
	Limit: 25.900 mm (1.0197 in)

Out of specification → Replace.

- 3.** Check:
- Surface of camshaft gear teeth
Crack/damage/wear → Replace.




- 4.** Check:
- Camshaft journal diameter “a”

	Camshaft journal diameter: 16.965–16.990 mm (0.6679–0.6689 in)
	Limit: 16.950 mm (0.6673 in)

Out of specification → Replace.

CHECKING THE VALVE LIFTERS


The following procedure applies to all of the valve lifters.



1. Check:
 - Valve lifterDamage → Replace.

CHECKING THE REED VALVE


1. Check:
 - Reed valveDamage → Replace.



INSTALLING THE VALVE LIFTERS AND CAMSHAFT

The following procedure applies to all of the camshaft and valve lifters.

1. Install:
 - Valve lifter “1” (Intake)
 - Valve lifter “2” (Exhaust)



2. Install:
 - Camshaft “1”


NOTICE

Be sure to align the camshaft gear mark “a” with the crankshaft gear mark “b”.

INSTALLING THE COVER 1

1. Clean:
 - Mating surfaces of the crankcase and the cover 1 (with a cloth dampened with lacquer thinner)


PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT



2. Apply:
 - Sealant
(onto the crankcase mating surfaces)



Three bond No.1217G®



3. Install:
 - Cover 1
 - Cover 1 bolts "1" to "5"

TIP


Tighten the bolts to the specified torque in order from "1" to "5".



**Cover 1 bolt:
9 N·m (0.9 kgf·m, 6.5 lb·ft)**

INSTALLING THE COVER 2

1. Install:
 - Gasket **New**
 - Cover 2
 - Cover 2 bolts "1" to "5"



TIP


Tighten the bolts to the specified torque in order from "1" to "5".




**Cover 2 bolt:
10 N·m (1.0 kgf·m, 7.2 lb·ft)**

CHECKING THE CRANKCASE COVER 1

1. Check:
 - Crankcase cover 1
Damage → Replace.
 - Bearing
Noise/wear/rotational failure → Replace.





INSTALLING THE CRANKCASE COVER 1

1. Install:
 - Crankcase cover 1
 - Crankcase cover 1 bolts “1” to “8”

TIP

Tighten the bolts to the specified torque in two steps and in order from “1” to “8”.



Crankcase cover 1 bolt:
1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft)
2nd: 30 N·m (3.0 kgf·m, 22 lb·ft)


CHECKING THE CYLINDERS AND PISTONS

The following procedure applies to all of the pistons and cylinders.

1. Check:
 - Piston wall
 - Cylinder wallVertical scratches → Replace the cylinder, and replace the piston and piston rings as a set.
2. Measure:
 - Cylinder warpage

TIP

Measure the warpage on the contact surface of the cylinder head at six points using a straight edge and feeler gauge set.



Feeler gauge set:
YU-26900-9



Warpage limit:
0.05 mm (0.002 in)


Out of specification → Replace the crankcase assembly.

3. Measure:
 - Piston-to-cylinder clearance



- a. Measure cylinder bore “C” with the cylinder bore gauge.

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT



TIP

Measure cylinder bore “C” by taking side-to-side and front-to-back measurements of the cylinder.

	Bore:
	80.000–80.020 mm (3.1496–3.1504 in)
	Warpage limit:
	80.025 mm (3.1506 in)

“C” = maximum of D₁, D₂, D₃, D₄, D₅, D₆

b. If out of specification, replace the crankcase assembly, and replace the piston and piston rings as a set.

c. Measure piston skirt diameter “P” with the micrometer.

a = 6.0 mm (0.2362 in) from the piston bottom edge

	Piston diameter:
	79.959–79.980 mm (3.1480–3.1488 in)
	Limit:
	79.900 mm (3.1457 in)

d. If out of specification, replace the piston and piston rings as a set.


e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance = Cylinder bore “C” – Piston skirt diameter “P”

	Piston-to-cylinder clearance:
	0.033–0.047 mm (0.0013–0.0019 in)
	Limit:
	0.15 mm (0.0059 in)

f. If out of specification, replace the crankcase assembly, and replace the piston and piston rings as a set.






CHECKING THE CRANKCASE


1. Check:
 - Crankcase
Damage → Replace.
 - Bearing
Noise/wear/rotational failure → Replace.

CHECKING THE PISTON PINS


The following procedure applies to all of the piston pins.


1. Check:
 - Piston pin
Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.
2. Measure:
 - Piston pin hole inside diameter “a”
Out of specifications → Replace.



	Piston pin hole inside diameter: 19.004–19.015 mm (0.7482–0.7486 in) Limit: 19.045 mm (0.7498 in)
--	--

3. Measure:
 - Piston pin diameter “a”
Out of specification → Replace.




	Piston pin diameter: 18.995–19.000 mm (0.7478–0.7480 in) Limit: 18.975 mm (0.7470 in)
---	--

4. Check:
 - Check that the piston pin enters smoothly into the piston pin hole.

TIP


If the piston pin fits too tight into the piston, check the piston pin hole. If there is any protrusion, use a knife or scraper to gently remove it so that piston pin can be pushed in smoothly with your fingers.



CHECKING THE PISTON RINGS

The following procedure applies to all of the piston rings.


PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT



1. Measure:
 - Piston ring side clearance
Out of specification → Replace the piston and piston rings as a set.

TIP


Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

	Piston ring
	Top ring
	Side clearance: 0.04–0.08 mm (0.0016–0.0031 in)
	Limit: 0.13 mm (0.0051 in)
	2nd ring
	Side clearance: 0.03–0.07 mm (0.0012–0.0028 in)
	Limit: 0.13 mm (0.0051 in)

2. Install:
 - Piston ring
(into the cylinder)


TIP

Use the piston crown to level the piston ring near bottom of cylinder “a”, where cylinder wear is lowest.




b. Upper of cylinder

3. Measure:
 - Piston ring end gap
Out of specification → Replace the piston rings as a set.


	Top ring
	End gap (installed): 0.20–0.35 mm (0.0079–0.0138 in)
	Limit: 0.60 mm (0.0236 in)
	2nd ring
	End gap (installed): 0.20–0.35 mm (0.0079–0.0138 in)
	Limit: 0.60 mm (0.0236 in)
	Oil ring
	End gap (installed): 0.20–0.70 mm (0.0079–0.0276 in)

CHECKING THE CRANKSHAFT

1. Check:
 - Crankshaft sprocket “1”
Damage/wear → Replace the crankshaft.




2. Measure:
 - Crankshaft runout limit
Out of specification → Replace.
Use a dial indicator gauge.




	Dial indicator gauge: YU-A8428
---	---

	Runout limit: 0.03 mm (0.0012 in)
---	--

3. Measure:
 - Crank pin outside diameter “a”
Out of specification → Replace.
Use a micrometer.




	Crank pin outside diameter: 40.950–41.050 mm (1.6122–1.6161 in)
---	--

CHECKING THE CONNECTING RODS OIL CLEARANCE

The following procedure applies to all of the connecting rods.

TIP _____

Measure the oil clearance if replacing the crankshaft or connecting rod.




1.

Place a piece of Plastigauge® “1” on the crank pin horizontally.


TIP _____

Wipe off oil thoroughly from the crankshaft, connecting rod, and connecting rod cap.




2.

- Install:
- Connecting rod “1”
 - Connecting rod cap “2”

	<p>Connecting rod cap bolt: 20 N·m (2.0 kgf·m, 14 lb·ft)</p>
--	---

TIP _____

Tighten the cap bolts so that the crankshaft does not move while the oil clearance is being measured.



3.


- Remove:
- Connecting rod cap
 - Connecting rod

4.

- Measure:
- Connecting rod big end oil clearance
Out of specification → Replace crankshaft or connecting rod assembly, and then measure the clearance again.

TIP _____


Measure the widest portion of the pressed Plastigauge®.

	<p>Connecting rod big end oil clearance: 0.016–0.046 mm (0.0006–0.0018 in) Limit: 0.09 mm (0.0035 in)</p>
---	---

INSTALLING THE PISTONS AND PISTON RINGS

The following procedure applies to all of the pistons, piston

PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT




rings and related components.

1. Install:
 - Top ring "1"
 - 2nd ring "2"
 - Oil ring "3"

TIP

- Be sure to install the top ring so that the "R" mark "a" faces toward the piston head.
- Be sure to install the 2nd ring so that the "RN" mark "b" faces toward the piston head.
- Make sure that the piston rings move smoothly.









2. Apply the engine oil to the inside of the connecting rod small end.

3. Install:
 - Piston "1"
 - Piston pin "2"
 - Piston pin circlips "3" **New**

TIP

- Make sure that the "▽" mark "a" on the piston head faces toward the flywheel.
- Install the piston pin clips so that the clip ends are 45° "b" or more from the cutout in the piston.





INSTALLING THE CRANKSHAFT

1. Make sure that the end gap of each piston ring is positioned correctly, as shown in the illustration.

- a. Top ring, oil ring expander
- b. Lower oil ring rail
- c. 2nd ring
- d. Upper oil ring rail

2. Install:

- Piston with the connecting rod "1"

3. Attach:

- Piston ring compressor "1"

	Piston ring compressor: YM-08037
--	---

TIP _____

Attach the piston ring compressor to the piston, and then insert the piston into the cylinder.


4. Check:

- Piston #1 with the connecting rod #1 "1" position

TIP _____

- Make sure that the "▽" mark "a" on the piston #1 head faces toward the flywheel.
- Make sure that the "7UD" mark "b" on the connecting rod #1 faces toward the crankcase cover 1.


PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT




- 5.** Check:
- Piston #2 with the connecting rod #2 “1” position.

TIP


- Make sure that the “▽” mark “a” on the piston #2 head faces toward the flywheel.
- Make sure that the “YAMAHA” mark “b” on the connecting rod #2 faces toward the crankcase cover 1.



- 6.** Install:
- Crankshaft “1”




- 7.** Install:
- Connecting rod cap #1 “1”
 - Connecting rod cap #1 bolts “2”

	Connecting rod cap bolt: 20 N·m (2.0 kgf·m, 14 lb·ft)
---	--

TIP



- Make sure that the “□” mark “a” on the connecting rod #1 is aligned with the “□” mark “b” on the connecting rod cap #1.
- Tighten the connecting rod cap #1 bolts alternately two to three times.



PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT

3

ENGINE



- 8.** Install:
- Connecting rod cap #2 “1”
 - Connecting rod cap #2 bolts “2”



Connecting rod cap bolt:
20 N·m (2.0 kgf·m, 14 lb·ft)


TIP

- Make sure that the “a” mark on the connecting rod #2 is aligned with the “b” mark on the connecting rod cap #2.
- Tighten the connecting rod cap #2 bolts alternately two to three times.

- 9.** Install:
- Camshaft
(Refer to “INSTALLING THE VALVE LIFTERS AND CAMSHAFT” on page 3-45)
 - Crankcase cover 1
(Refer to “INSTALLING THE CRANKCASE COVER 1” on page 3-47)

FUEL

FUEL PUMPS



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the fuel pumps		Remove the parts in the order listed.
1	Fuel filter	1	
2	Fuel hose	1	
3	Low-pressure fuel pump	1	
4	Fuel pump bracket	1	
5	Fuel injector pipe 1	1	Disconnect.
6	Purge hose 2	1	Disconnect.
7	High-pressure fuel pump lead coupler	1	Disconnect.
8	High-pressure fuel pump	1	
9	Fuel pump bracket	1	
10	Pulsar hose	1	
11	Fuel delivery hose	1	

REMOVING THE HIGH-PRESSURE FUEL PUMP





⚠ WARNING

Cover fuel injector pipe 1 connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the fuel injector pipe 1.

1. Disconnect:
 - Fuel injector pipe 1 “1”

NOTICE

Be sure to disconnect the fuel injector pipe 1 “1” by hand. Do not forcefully disconnect the hose with tools.



TIP


- To remove the fuel injector pipe 1 from the high-pressure fuel pump joint, press the two buttons “2” on the sides of the connector, and then remove the pipe.
- Before removing the pipe, place a few rags in the area under where it will be removed.

2. Disconnect:
 - High-pressure fuel pump lead coupler

TIP

Slide the coupler cover “a” upward as shown in the illustration, and remove the coupler.

3. Remove:
 - High-pressure fuel pump



CHECKING THE LOW-PRESSURE FUEL PUMP

1. Check:

- Fuel hose “1”
- Fuel delivery hose “2”
- Pulsar hose “3”
- Low-pressure fuel pump “4”
Cracks/damage → Replace.

2. Check:

- Low-pressure fuel pump operation



- a. Connect the manual vacuum pump (Pressure/vacuum tester) “1” to the pulsar hose “2”.

	<p>Pressure/vacuum tester: YB-35956-B</p>
---	--

- b. Place the container underneath the end of the fuel delivery hose “3”.
- c. Operate the manual vacuum pump (Pressure/vacuum tester) “1” and check that gasoline is flowing out of the fuel delivery hose “3”.
- d. If not, replace the fuel pump assembly.



CHECKING THE HIGH-PRESSURE FUEL PUMP

1. Check:


- High-pressure fuel pump
Cracks/damage → Replace.

2. Check:

- Fuel pressure




- a. Disconnect the fuel injector pipe 1 “1” from the fuel pump.
Refer to “REMOVING THE HIGH-PRESSURE FUEL PUMP” on page 4-2.



⚠ WARNING _____

Cover fuel injector pipe 1 connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the fuel injector pipe 1.



NOTICE

Be sure to disconnect the fuel injector pipe 1 by hand. Do not forcefully disconnect the hose with tools.

- b. Connect the Fuel pressure gauge “2” and fuel pressure adapter “3” to the fuel injector pipe 1.

	<p>Fuel pressure gauge: YU-03153</p> <p>Fuel pressure adapter: YM-03186</p>
--	---


- c. Start the engine.
 - d. Measure the fuel pressure.
- Faulty → Replace the fuel pump.

	<p>Fuel line pressure (at idle): 255–285 kPa (2.55–2.85 kgf/cm², 36.98–41.33 psi)</p>
--	---




INSTALLING THE HIGH-PRESSURE FUEL PUMP

1. Install:
 - High-pressure fuel pump
2. Connect:
 - High-pressure fuel pump lead coupler



TIP

Insert the coupler securely, slide the coupler cover “a” downward as shown in the illustration, and then lock the coupler.



3. Connect:
 - Fuel injector pipe 1

NOTICE

When connecting the fuel injector pipe 1, make sure that it is securely connected, and that the fuel injector pipe 1 connector on the fuel injector pipe 1 is in the correct position, otherwise the fuel injector pipe 1 will not be properly installed.

TIP

Install the fuel injector pipe 1 securely onto the high-pres-

FUEL PUMPS


sure fuel pump joint until a distinct “click” is heard.

THROTTLE BODY ASSEMBLY

THROTTLE BODY ASSEMBLY

4

FUEL




Order	Job/Parts to remove	Q'ty	Remarks
	Removing the throttle body assembly		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
1	Governor spring	1	
2	Governor assembly	1	
3	Throttle lever comp	1	
4	Link rod/spring	1/1	
5	Stay	1	
6	Breather hose	1	
7	Joint 1	1	
8	Gasket	1	
9	Throttle body assembly lead coupler	1	Disconnect.
10	Throttle body assembly	1	
11	Gasket	1	

THROTTLE BODY ASSEMBLY

REMOVING THE THROTTLE BODY ASSEMBLY

1. Remove:
 - Governor spring
 - Governor assembly
 - Throttle lever comp
 - Link rod/spring
2. Remove:
 - Stay "1"
 - Breather hose "2"
 - Joint 1 "3"
 - Throttle body assembly "4"
 - Gaskets "5"





CHECKING THE THROTTLE BODY ASSEMBLY

1. Check:
 - Throttle body assembly
Cracks/damage → Replace.
2. Check:
 - Throttle valve operation
Throttle valve can not move smoothly → Replace.
 - Engine speed adjustment
Can not adjust engine high/low engine speed by procedure on page 2-16 → Replace.

INSTALLING THE THROTTLE BODY ASSEMBLY

1. Install:
 - Gaskets "1" **New**
 - Throttle body assembly "2"
 - Joint 1 "3"
 - Breather hose "4"
 - Stay "5"
 - Throttle body assembly nuts




	Throttle body assembly nut: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	--

THROTTLE BODY ASSEMBLY

4

FUEL



- 2. Install:**
- Link rod/spring
 - Throttle lever comp
 - Governor assembly
 - Governor spring "1"

TIP

- Install the bending portion (short) "a" of the governor spring "1" into the hole "c" of the throttle lever comp while installing the bending portion (long) "b" of the governor spring "1" into the hole "d" of the governor assembly.
- Install the governor spring to the throttle lever comp first, and then to the governor assembly.

- 3. Adjust:**
- Governor
 - Governor assembly



- a. Loosen the governor assembly bolt "1".
- b. Turn the governor assembly "2" counterclockwise until it stops.
- c. Turn the governor fork "3" counterclockwise until it stops.
- d. Tighten the governor assembly bolt "1".



Governor assembly bolt:
8 N·m (0.8 kgf·m, 5.8 lb·ft)




- 4. Check:**
- Engine speed
(Refer to "ENGINE SPEED" on page 2-14)



High engine speed (with no load):
3550–3600 r/min
Low engine speed (with no load):
1450–1550 r/min

FUEL INJECTORS AND INTAKE MANIFOLD

FUEL INJECTORS AND INTAKE MANIFOLD



4


FUEL

Order	Job/Parts to remove	Q'ty	Remarks
	Removing the fuel injectors and intake manifold		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER" on page 3-3.
	ECU and rectifier/regulator		Refer to "ECU, RECTIFIER/REGULATOR, AND FUSES" on page 3-8.
	Low-pressure fuel pump		Refer to "FUEL PUMPS" on page 4-1.
	Oil cooler		Refer to "OIL COOLER" on page 3-5.
	Fan case and fan		Refer to "CASE AND FAN" on page 3-11.
	Throttle body assembly		Refer to "THROTTLE BODY ASSEMBLY" on page 4-6.
	Ignition coil		Refer to "IGNITION COILS" on page 3-10.
1	Purge hose	1	
2	Fuel injector #1 lead coupler	1	Disconnect.
3	Fuel injector #2 lead coupler	1	Disconnect.

FUEL INJECTORS AND INTAKE MANIFOLD

4

FUEL



Order	Job/Parts to remove	Q'ty	Remarks
4	Manifold absolute pressure sensor lead coupler	1	Disconnect.
5	Fuel injector pipe 1	1	
6	Fuel injector pipe 2	1	
7	Inlet pipe 1	1	
8	Inlet pipe 2	1	
9	Fuel injector #1	1	
10	Fuel injector #2	1	
11	Intake manifold	1	
12	Intake manifold joint	2	
13	Gasket	4	
14	Manifold absolute pressure sensor	1	

REMOVING THE FUEL INJECTORS

The following procedure applies to all of the fuel injectors and related components.




1. Remove:
 - Air filter case
(Refer to “AIR FILTER” on page 3-3)
 - ECU and rectifier/regulator
(Refer to “ECU, RECTIFIER/REGULATOR, AND FUSES” on page 3-8)
 - Low-pressure fuel pump
(Refer to “FUEL PUMPS” on page 4-1)
 - Oil cooler
(Refer to “OIL COOLER” on page 3-5)
 - Fan case and fan
(Refer to “CASE AND FAN” on page 3-11)
 - Throttle body assembly
(Refer to “THROTTLE BODY ASSEMBLY” on page 4-6)
 - Ignition coil
(Refer to “IGNITION COILS” on page 3-10)

2. Remove:
 - Hose clamp (Clic-R)
(Refer to “REMOVING THE OIL COOLER” on page 3-6)
 - Fuel injector pipe 1 “1”
 - Fuel injector pipe 2 “2”

3. Disconnect:
 - Fuel injector lead coupler

TIP


Slide the coupler cover “a” upward as shown in the illustration, and remove the coupler.



FUEL INJECTORS AND INTAKE MANIFOLD

4

FUEL



4. Remove:
- Fuel injector

TIP

Remove the fuel injector “1” with the inlet pipe “2” installed.

5. Remove:
- Inlet pipe

TIP

After removing the retainer “1”, remove the inlet pipe “2” from the fuel injector.


6. Check:
- Fuel injectors
Obstruction → Replace and check the fuel pump/ fuel supply system.
Deposit → Replace.
Damage → Replace.

7. Check:
- Fuel injector resistance
(Refer to “CHECKING THE FUEL INJECTORS” on page 5-35)


INSTALLING THE FUEL INJECTORS

The following procedure applies to all of the fuel injectors and related components.

1. Install:
- Fuel injector “1”
 - O-ring “2” **New**
 - Inlet pipe “3”




FUEL INJECTORS AND INTAKE MANIFOLD



- 2.** Install:
- Retainer “1”

TIP

Engage the claw “a” of the retainer with the projection “b” on the fuel injector, and install to the fuel injector.



- 3.** Install:
- Fuel injector

TIP

Engage the projection “a” on the fuel injector with the groove “b” in the intake manifold, and install to the intake manifold.

- Inlet pipe bolts




Inlet pipe bolt:
9 N·m (0.9 kgf·m, 6.5 lb·ft)

- 4.** Connect:
- Fuel injector lead coupler

TIP

Insert the coupler securely, slide the coupler cover “a” downward as shown in the illustration, and then lock the coupler.




- 5.** Install:
- Hose clamp (Clic-R) **New**
(Refer to “INSTALLING THE OIL COOLER” on page 3-6)
 - Fuel injector pipe 1
 - Fuel injector pipe 2

- 6.** Install:
- Ignition coil
(Refer to “IGNITION COILS” on page 3-10)
 - Throttle body assembly
(Refer to “THROTTLE BODY ASSEMBLY” on page 4-6)
 - Fan case and fan
(Refer to “CASE AND FAN” on page 3-11)
 - Oil cooler
(Refer to “OIL COOLER” on page 3-5)
 - Low-pressure fuel pump
(Refer to “FUEL PUMPS” on page 4-1)

- ECU and rectifier/regulator
(Refer to “ECU, RECTIFIER/REGULATOR, AND FUSES” on page 3-8)
- Air filter case
(Refer to “AIR FILTER” on page 3-3)

REMOVING THE MANIFOLD ABSOLUTE PRESSURE SENSOR

1. Disconnect:
 - Manifold absolute pressure sensor lead coupler




TIP

Slide the lock “a” of the coupler as shown in the illustration, and remove the coupler.

2. Remove:
 - Manifold absolute pressure sensor

INSTALLING THE MANIFOLD ABSOLUTE PRESSURE SENSOR


1. Install:
 - Manifold absolute pressure sensor
 - O-ring **New**
 - Manifold absolute pressure sensor bolt

	Manifold absolute pressure sensor bolt: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
---	---

2. Connect:
 - Manifold absolute pressure sensor lead coupler


TIP

Insert the coupler securely, slide the lock “a” of the coupler as shown in the illustration, and install the coupler.



REMOVING THE INTAKE MANIFOLD

1. Remove:
 - Fuel injectors
(Refer to “REMOVING THE FUEL INJECTORS” on page 4-11)




- Remove:
 - Intake manifold “1”
 - Intake manifold joints “2”
 - Gaskets “3”

CHECKING THE INTAKE MANIFOLD


- Check:
 - Intake manifold
 - Intake manifold joints
 - Cracks/damage → Replace.

INSTALLING THE INTAKE MANIFOLD

- Install:
 - Gaskets “1” **New**
 - Intake manifold joints “2”
 - Intake manifold “3”



- Install:
 - Intake manifold nuts “1”–“4” and bolts “5”–“8”



TIP

Tighten the bolts and nuts to the specified torque in two steps and in order from “1” to “8”.


	Intake manifold nut and bolt:
	1st: 3.0 N·m (0.30 kgf·m, 2.2 lb·ft)
	2nd: 7 N·m (0.7 kgf·m, 5.1 lb·ft)

- Install:
 - Fuel injectors
 - (Refer to “INSTALLING THE FUEL INJECTORS” on page 4-12)

ELECTRICAL

CIRCUIT DIAGRAM

ELECTRICAL 5



CIRCUIT DIAGRAM

- | | |
|------------------------------|---------------------------------------|
| 1. ECU (Engine Control Unit) | 14. Rollover switch |
| 2. Stator coil assembly | 15. FI diagnostic tool coupler |
| 3. Rectifier/regulator | 16. Engine temperature sensor |
| 4. Fuse (30 A) | 17. Manifold absolute pressure sensor |
| 5. Fuse (10 A) | 18. Throttle position sensor |
| 6. Fuse (10 A) | 19. O ₂ sensor |
| 7. Oil pressure switch | 20. Crankshaft position sensor |
| 8. Starter relay | 21. High-pressure fuel pump |
| 9. Starter motor | 22. Ignition coil #2 |
| 10. Battery | 23. Ignition coil #1 |
| 11. Main switch | 24. Fuel injector #1 |
| 12. Mil light | 25. Fuel injector #2 |
| 13. Oil warning light | |

Color code

B	Black	G/R	Green/Red
Br	Brown	G/W	Green/White
G	Green	G/Y	Green/Yellow
Gy	Gray	L/O	Blue/Orange
L	Blue	L/W	Blue/White
O	Orange	P/L	Pink/Blue
R	Red	R/L	Red/Blue
V	Violet	R/W	Red/White
W	White	R/Y	Red/Yellow
Y	Yellow	W/B	White/Black
B/W	Black/White	W/R	White/Red
Br/G	Brown/Green	Y/L	Yellow/Blue

FUEL INJECTION SYSTEM

FUEL INJECTION SYSTEM

FI DIAG TOOL INSTRUCTIONS

Purpose

This FI Diagnostic Tool is to diagnose electronic fuel injection system used on Yamaha MX825V-EFI, MX800V-EFI and MX775V-EFI engines.

Functions


There are 5 Modes in this diag tool.

- “CURRENT”
Displays current error codes.
- “DIAG”
Displays sensor output.
- “HISTORY”
Displays history error codes.
(Diag tool display 1 history error code, if the same error happened in the past.)
- “CLEAR”
Deletes history error codes.
- “PROPERTY”
Display ECU property. (Not needed for usual maintenance)

Operation

- CONNECTING AND DISCONNECTING

- 1.** Turn the main switch “OFF”.
- 2.** Connect the FI Diagnostic Tool to the engine coupler “1”.
- 3.** Turn the main switch “ON”.



FUEL INJECTION SYSTEM

BUTTONS AND LEDs

The “UP” button “1”/“DOWN” button “2”

1. The “UP”/“DOWN” buttons are used to scroll each MODE.
2. The “UP”/“DOWN” buttons are used to decide “YES” or “NO” to delete history error code in “CLEAR” mode.
3. Reboot FI Diagnostic Tool to push “UP”/“DOWN” buttons simultaneously for more than 3 seconds.

“MODE” button “3”

The “MODE” button is used to move to MODE select function, and decide the operating MODE.

“POWER” LED (Green) “4”


The LED comes on when power (Main Switch Voltage) is supplied to the FI Diagnostic Tool.

“WARNING” LED (Orange) “5”

The LED comes on when error code is detected in “CURRENT” MODE.

LCD Display “6”


This LCD display indicates error codes, sensor outputs, engine run hours, currently selected MODE or function.



FUEL INJECTION SYSTEM

Operation (BUTTONS and LEDs)

ELECTRICAL 5




- | | |
|--|--------------|
| 1. CONNECT | 10. SELECT |
| 2. CONNECTED | 11. CURRENT |
| 3. CHANGE MODE | 12. SELECT |
| 4. (EACH) MODE | 13. CURRENT |
| 5. DETERMINE MODE | 14. DIAG |
| 6. FAILED | 15. HISTORY |
| 7. Reboot (UP+DOWN) (Simultaneously more than 3 seconds) | 16. CLEAR |
| 8. WAITING | 17. PROPERTY |
| 9. COM ERROR | |

FUEL INJECTION SYSTEM

Details

• “CURRENT” MODE


Display when there is error



- 1. Selected Mode
- 2. Error Code

- 3. Total number of Error Code
- 4. Current page number on display

Display when there is no error



- 1. Selected Mode

- 2. Message


• “DIAG” MODE

Diag Code	Item	What to display	Unit
MAP	Manifold Absolute Pressure Sensor	Manifold Absolute Pressure	psi
IAT	Intake Air Temperature Sensor	Intake Air Temperature	°F
ET	Engine Temperature Sensor	Engine Temperature	°F
TPS	Throttle Position Sensor	Throttle Valve position	%
O ₂	O ₂ sensor	Oxygen density	V
RPM	Engine rpm	Engine rpm	rpm
HOUR	Engine run hour	Engine run hour	hr

FUEL INJECTION SYSTEM

5


ELECTRICAL



- 1. Selected Mode
- 2. Selected Diag Code
- 3. Unit
- 4. Sensor output

• “HISTORY” MODE

Display when there is error code in the past



- 1. Selected Mode
- 2. Error Code
- 3. Total number of Error Code
- 4. Current page number on display


Display there is no error code in the past



- 1. Selected Mode
- 2. Message

FUEL INJECTION SYSTEM

- “CLEAR” MODE



- 1. Question: Delete?
- 2. “DOWN” button: NO
- 3. “UP” button: YES

- 4. CANCELED
- 5. DELETED


- “PROPERTY” MODE

This MODE is not needed for usual maintenance.

FUEL INJECTION SYSTEM

FUEL INJECTION DIAGRAM

5
ELECTRICAL



- 1. Fuel filter
 - 2. Fuel pump (low pressure)
 - 3. Fuel pump (high pressure)
 - 4. Fuel injector
 - 5. ECU (Engine Control Unit)
 - 6. Throttle position sensor
 - 7. Ignition coil
 - 8. O₂ sensor
 - 9. Engine temperature sensor
 - 10. Crankshaft position sensor
 - 11. Throttle body
 - 12. Manifold absolute pressure sensor
 - 13. Air filter case
 - 14. Muffler
- A. Fuel system
B. Air system
C. Control system

FUEL INJECTION SYSTEM

ERROR CODE LIST

Error Code	System or Component	Detail
P0107	Manifold Absolute Pressure Sensor (MAP)	MAP Circuit Low Voltage or Open
P0108	Manifold Absolute Pressure Sensor (MAP)	MAP Circuit High Voltage
P0112	Intake Air Temperature Sensor (IAT)	IAT Circuit Low Voltage
P0113	Intake Air Temperature Sensor (IAT)	IAT Circuit High Voltage or Open
P0117	Engine Temperature Sensor (ET)	Engine Temperature Sensor Circuit Low Voltage
P0118	Engine Temperature Sensor (ET)	Engine Temperature Sensor Circuit High Voltage or Open
P0122	Throttle Position Sensor (TPS)	TPS Circuit Low Voltage or Open
P0123	Throttle Position Sensor (TPS)	TPS Circuit High Voltage
P0131	Oxygen Sensor (O ₂)	Circuit Low Voltage
P0132	Oxygen Sensor (O ₂)	Circuit High Voltage
P0032	Oxygen Sensor Heater	Heater Circuit High Voltage
P0031	Oxygen Sensor Heater	Heater Circuit Low Voltage
P0201	Fuel Injector	Injector #1 Circuit Malfunction
P0202	Fuel Injector	Injector #2 Circuit Malfunction
P0230	Fuel Pump Relay (FPR)	FPR Coil Circuit Low Voltage or Open
P0232	Fuel Pump Relay (FPR)	FPR Coil Circuit High Voltage
P0336	Crankshaft Position Sensor (CPS)	CPS Sensor Noisy Signal
P0337	Crankshaft Position Sensor (CPS)	CPS Sensor No Signal
P0351	Ignition Coil	Cylinder #1 Ignition Coil Malfunction
P0352	Ignition Coil	Cylinder #2 Ignition Coil Malfunction
P0562	System Voltage	System Voltage Low
P0563	System Voltage	System Voltage High
P0650	MIL	MIL Circuit Malfunction
P0171	BLM MaxAdapt	Correction amount of injection fuel is beyond upper limit
P0172	BLM MinAdapt	Correction amount of injection fuel is beyond lower limit
P0174	PE system Lean	Lean fuel ratio

FUEL INJECTION SYSTEM

DIAG CODE LIST

DIAG Tool Mode	Diag Code	Item	What to display	Unit	How to diagnosis
DIAG	MAP	Manifold Absolute Pressure sensor	Manifold Absolute Pressure	psi	<ul style="list-style-type: none"> Compare the sensor output value with atmospheric absolute pressure (Example: 14.7 psi) with engine stopped. Confirm the sensor output value on display changes while engine cranking. (Manifold Absolute pressure changes during cranking.)
	IAT	Intake Air Temperature Sensor	Intake Air Temperature	°F	<ul style="list-style-type: none"> Compare the sensor output value with ambient air temperature. (with engine cold) Confirm the sensor output value on display changes with heating or cooling sensor alone.
	ET	Engine Temperature Sensor	Engine Temperature	°F	<ul style="list-style-type: none"> Compare the sensor output value with ambient air temperature. (with engine cold) Confirm the sensor output value on display changes with heating or cooling sensor alone. Sensor resistance: 9.0–11.0 kΩ (25 °C)
	TPS	Throttle Position Sensor	Throttle Valve position	%	<ul style="list-style-type: none"> Confirm throttle position on FI diagnostic tool display when throttle valve is fully opened. MX825V: 95–100 % MX800V: 67–77 % MX775V: 54–64 % Confirm throttle position on FI diagnostic tool display when throttle valve is fully closed. MX825/800/775V: 0–5 % Confirm throttle position on display changes smoothly with throttle valve open and close.
	O ₂	O ₂ sensor	Oxygen density	V	—
	RPM	Engine rpm	Engine rpm	rpm	—
	HOUR	Engine run hour	Engine run hour	hr	—

FUEL INJECTION SYSTEM

FUEL INJECTION SYSTEM TROUBLESHOOTING

Error Code No. P0107, P0108

Error Code	P0107
System or Component	Manifold Absolute Pressure Sensor (MAP)
Detail of Error	MAP Circuit Low Voltage or Open
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start • Poor driveability • Deteriorated exhaust
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "MAP"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with atmospheric absolute pressure (Example: 14.7 psi) with engine stopped. • Confirm the sensor output value on display changes while engine cranking. (Manifold Absolute pressure changes during cranking.)
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Open or low voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU • Vacuum leak from intake manifold

Error Code	P0108
System or Component	Manifold Absolute Pressure Sensor (MAP)
Detail of Error	MAP Circuit High Voltage
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "MAP"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with atmospheric absolute pressure (Example: 14.7 psi) with engine stopped. • Confirm the sensor output value on display changes while engine cranking. (Manifold Absolute pressure changes during cranking.)
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • High Voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU • Vacuum leak from intake manifold

FUEL INJECTION SYSTEM

Error Code No. P0112, P0113

Error Code	P0112
System or Component	Intake Air Temperature Sensor (IAT)
Detail of Error	IAT Circuit Low Voltage
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "IAT"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with ambient air temperature. (with engine cold) • Confirm the sensor output value on display changes with heating or cooling sensor alone.
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

Error Code	P0113
System or Component	Intake Air Temperature Sensor (IAT)
Detail of Error	IAT Circuit High Voltage or Open
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "IAT"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with ambient air temperature. (with engine cold) • Confirm the sensor output value on display changes with heating or cooling sensor alone.
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • High voltage or open in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0117, P0118

Error Code	P0117
System or Component	Engine Temperature Sensor (ET)
Detail of Error	Engine Temperature Sensor Circuit Low Voltage
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "ET"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with ambient air temperature. (with engine cold) • Confirm the sensor output value on display changes with heating or cooling sensor alone. • Sensor resistance: 9.0–11.0 kΩ at 25 °C (77 °F)
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

Error Code	P0118
System or Component	Engine Temperature Sensor (ET)
Detail of Error	Engine Temperature Sensor Circuit High Voltage or Open
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "ET"
Diagnosing	<ul style="list-style-type: none"> • Compare the sensor output value with ambient air temperature. (with engine cold) • Confirm the sensor output value on display changes with heating or cooling sensor alone. • Sensor resistance: 9.0–11.0 kΩ at 25 °C (77 °F)
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • High voltage or open in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0122, P0123

Error Code	P0122
System or Component	Throttle Position Sensor (TPS)
Detail of Error	TPS Circuit Low Voltage or Open
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling (Different idling engine rpm) • Limited engine performance
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "TPS"
Diagnosing	<ul style="list-style-type: none"> • Confirm throttle position on FI diagnostic tool display when throttle valve is fully opened. MX825V: 95–100 % MX800V: 67–77 % MX775V: 54–64 % • Confirm throttle position on FI diagnostic tool display when throttle valve is fully closed. MX825/800/775V: 0–5 % • Confirm throttle position on display changes smoothly with throttle valve open and close.
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage or open in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

Error Code	P0123
System or Component	Throttle Position Sensor (TPS)
Detail of Error	TPS Circuit High Voltage
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling (Different idling engine rpm) • Limited engine performance
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "TPS"
Diagnosing	<ul style="list-style-type: none"> • Confirm throttle position on FI diagnostic tool display when throttle valve is fully opened. MX825V: 95–100 % MX800V: 67–77 % MX775V: 54–64 % • Confirm throttle position on FI diagnostic tool display when throttle valve is fully closed. MX825/800/775V: 0–5 % • Confirm throttle position on display changes smoothly with throttle valve open and close.
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage or open in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0131, P0132

Error Code	P0131
System or Component	Oxygen Sensor
Detail of Error	Circuit Low Voltage
Engine Symptoms	Deteriorated exhaust
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "O ₂ "
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

Error Code	P0132
System or Component	Oxygen Sensor
Detail of Error	Circuit High Voltage
Engine Symptoms	Deteriorated exhaust
Engine Running availability	Able to run engine
DIAG Tool Code	Mode "DIAG", Code "O ₂ "
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • High voltage in wire harness between sensor and ECU • Malfunction in sensor unit • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0032, P0031

Error Code	P0032
System or Component	Oxygen Sensor Heater
Detail of Error	Heater Circuit High Voltage
Engine Symptoms	Deteriorated exhaust (until exhaust gas heated after engine starts)
Engine Running availability	Able to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • High voltage in wire harness between sensor and ECU • Malfunction in sensor (heater) unit • Malfunction in ECU

Error Code	P0031
System or Component	Oxygen Sensor Heater
Detail of Error	Heater Circuit Low Voltage
Engine Symptoms	Deteriorated exhaust (until exhaust gas heated after engine starts)
Engine Running availability	Able to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Low voltage in wire harness between sensor and ECU • Malfunction in sensor (heater) unit • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0201, P0202

Error Code	P0201
System or Component	Fuel Injector
Detail of Error	Injector #1 Circuit Malfunction
Engine Symptoms	Cylinder #1 stops
Engine Running availability	Able to run with Cylinder #2 alone
DIAG Tool Code	—
Diagnosing	Fuel injector resistance 11.4–12.6 Ω
Probable Cause	<ul style="list-style-type: none">• Malfunction in wire harness and coupler between injector and ECU• Shorted or open in wire harness between sensor and ECU• Malfunction in injector• Malfunction in ECU

Error Code	P0202
System or Component	Fuel Injector
Detail of Error	Injector #2 Circuit Malfunction
Engine Symptoms	Cylinder #2 stops
Engine Running availability	Able to run with Cylinder #1 alone
DIAG Tool Code	—
Diagnosing	Fuel injector resistance 11.4–12.6 Ω
Probable Cause	<ul style="list-style-type: none">• Malfunction in wire harness and coupler between injector and ECU• Shorted or open in wire harness between sensor and ECU• Malfunction in injector• Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0230, P0232

Error Code	P0230
System or Component	Fuel Pump Relay (FPR)
Detail of Error	FPR Coil Circuit Low Voltage or Open
Engine Symptoms	<ul style="list-style-type: none"> • Engine stop • Unable to start engine
Engine Running availability	Unable to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between pump and ECU • Low voltage or open in wire harness between pump and ECU • Malfunction in pump • Malfunction in ECU

Error Code	P0232
System or Component	Fuel Pump Relay (FPR)
Detail of Error	FPR Coil Circuit High Voltage
Engine Symptoms	<ul style="list-style-type: none"> • Engine stop • Unable to start engine
Engine Running availability	Unable to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between pump and ECU • High voltage in wire harness between pump and ECU • Malfunction in pump • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0336, P0337

Error Code	P0336
System or Component	Crankshaft Position Sensor (CPS)
Detail of Error	CPS Sensor Noisy Signal
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Depends on the case
DIAG Tool Code	—
Diagnosing	Crankshaft position sensor resistance 3.0–7.0 kΩ
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Malfunction in sensor installing (loose sensor, dirty sensor, air gap) • Malfunction in sensor unit • Malfunction in ECU • Malfunction in rotor (damaged, deformed)

Error Code	P0337
System or Component	Crankshaft Position Sensor (CPS)
Detail of Error	CPS Sensor No Signal
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling
Engine Running availability	Depends on the case
DIAG Tool Code	—
Diagnosing	Crankshaft position sensor resistance 3.0–7.0 kΩ
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between sensor and ECU • Shorted or open in wire harness between sensor and ECU • Malfunction in sensor installing (loose sensor, dirty sensor, air gap) • Malfunction in sensor unit • Malfunction in ECU • Malfunction in rotor (damaged, deformed)

FUEL INJECTION SYSTEM

Error Code No. P0351, P0352

ELECTRICAL 5

Error Code	P0351
System or Component	Ignition Coil
Detail of Error	Cylinder #1 Ignition Coil Malfunction
Engine Symptoms	Cylinder #1 stops operating (Injector also stops operating.)
Engine Running availability	Able to run with Cylinder #2 alone
DIAG Tool Code	—
Diagnosing	<ul style="list-style-type: none"> • Primary coil resistance 0.44–0.66 Ω • Secondary coil resistance 5.6–8.4 Ω
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between coil and ECU • Shorted or open in wire harness between coil and ECU • Malfunction in coil • Malfunction in ECU

Error Code	P0352
System or Component	Ignition Coil
Detail of Error	Cylinder #2 Ignition Coil Malfunction
Engine Symptoms	Cylinder #2 stops operating (Injector also stops operating)
Engine Running availability	Able to run with Cylinder #1 alone
DIAG Tool Code	—
Diagnosing	<ul style="list-style-type: none"> • Primary coil resistance 0.44–0.66 Ω • Secondary coil resistance 5.6–8.4 Ω
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between coil and ECU • Shorted or open in wire harness between coil and ECU • Malfunction in coil • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0562, P0563

Error Code	P0562
System or Component	System Voltage
Detail of Error	System Voltage Low
Engine Symptoms	<ul style="list-style-type: none"> • Engine stop • Unable to start engine
Engine Running availability	Depends on the case
DIAG Tool Code	—
Diagnosing	Confirm battery voltage
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between battery and ECU • Shorted or open in wire harness between battery and ECU • Malfunction in battery • Malfunction in charging system • Malfunction in ECU

Error Code	P0563
System or Component	System Voltage
Detail of Error	System Voltage High
Engine Symptoms	<ul style="list-style-type: none"> • Engine stop • Unable to start engine
Engine Running availability	Depends on the case
DIAG Tool Code	—
Diagnosing	Confirm battery voltage
Probable Cause	<ul style="list-style-type: none"> • Malfunction in wire harness and coupler between battery and ECU • Shorted or open in wire harness between battery and ECU • Malfunction in battery • Malfunction in charging system • Malfunction in ECU

FUEL INJECTION SYSTEM

Error Code No. P0171, P0172, P0174

Error Code	P0171
System or Component	BLM MaxAdapt
Detail of Error	Correction amount of injection fuel is beyond upper limit
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling (Different idling engine rpm)
Engine Running availability	Able to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Fuel system malfunction (Clogged fuel filter/line, fuel injector, fuel pump) • Malfunction in O₂ sensor • Malfunction in manifold absolute pressure sensor • Difference of actual intake air volume (Intake air leak, clogged manifold, dirty/restricted air filter) • Malfunction in ECU • Malfunction in wiring harness

Error Code	P0172
System or Component	BLM MinAdapt
Detail of Error	Correction amount of injection fuel is beyond lower limit
Engine Symptoms	<ul style="list-style-type: none"> • Poor engine start (There is possibility it can't start) • Poor driveability • Deteriorated exhaust • Unstable engine idling (Different idling engine rpm) • Overheat • Engine knock sound
Engine Running availability	Able to run engine
DIAG Tool Code	—
Diagnosing	—
Probable Cause	<ul style="list-style-type: none"> • Fuel system malfunction (Clogged fuel filter/line, fuel injector, fuel pump) • Malfunction in O₂ sensor • Malfunction in manifold absolute pressure sensor • Difference of actual intake air volume (Intake air leak, clogged manifold, dirty/restricted air filter) • Malfunction in ECU • Malfunction in wiring harness

FUEL INJECTION SYSTEM


Error Code	P0174
System or Component	PE system Lean
Detail of Error	Lean fuel ratio
Engine Symptomes	<ul style="list-style-type: none"> • Poor drivability • Deteriorated exhaust • Unstable engine idling (Different idling engine rpm) • Overheat • Engine knock sound
Engine Running availability	Able to run engine
DIAG Tool Code	—
How to Diagnosis	—
Probable Cause	<ul style="list-style-type: none"> • Fuel system malfunction (Clogged fuel filter/line, fuel injector, fuel pump) • Malfunction in O₂ sensor • Malfunction in manifold absolute pressure sensor • Difference of actual intake air volume (Intake air leak/clogged manifold) • Running out fuel

ELECTRICAL COMPONENTS

ELECTRICAL COMPONENTS


5

ELECTRICAL



ELECTRICAL COMPONENTS

1. Manifold absolute pressure sensor
2. Fuel injector
3. Engine temperature sensor
4. High-pressure fuel pump
5. Oil pressure switch
6. Ignition coil/spark plug cap
7. Stator coil assembly
8. Rectifier/regulator
9. Crankshaft position sensor
10. Throttle position sensor
11. O₂ sensor
12. ECU (Engine Control Unit)
13. Fuse
14. Starter motor



CHECKING THE SWITCH CONTINUITY

Check each switch for continuity with the tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

NOTICE

Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.

	<p>Model 88 Multimeter with tachometer: YU-A1927</p>
---	---

TIP



- Before checking for continuity, set the digital circuit tester to the “Ω” range.
- When checking for continuity, switch back and forth between the switch positions a few times.

CHECKING THE FUSES

The following procedure applies to all of the fuses.

NOTICE

To avoid a short circuit, always set the main switch to “OFF” when checking or replacing a fuse.



1. Remove:
 - Fuse “1”
2. Check:
 - Fuse



- a. Connect the digital circuit tester to the fuse and check the continuity.

TIP _____
Set the digital circuit tester selector to “Ω”.

	Model 88 Multimeter with tachometer: YU-A1927
---	--


b. If the digital circuit tester indicates “O.L.”, replace the fuse.




3. Replace:
• Blown fuse



- a. Set the main switch to “OFF”.
- b. Install a new fuse of the correct amperage.
- c. Set the main switch to “ON” and verify if the electrical circuit is operational.
- d. If the fuse immediately blows again, check the electrical circuit.



	Fuse amperage “a”: 30 A × 1
	Fuse amperage “b”: 10 A × 2


⚠ WARNING _____
Never use a fuse with an amperage other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system and could possibly cause a fire.



4. Install:
• Fuse

CHECKING THE OIL PRESSURE SWITCH

- 1.** Drain:
 - Engine oil
- 2.** Disconnect:
 - Oil pressure switch lead



3. Connect:
 - Digital circuit tester
(between the engine ground and oil pressure switch terminal)

	Model 88 Multimeter with tachometer: YU-A1927
--	--

4. Check:
 - Oil pressure switch continuity
No continuity → Replace the oil pressure switch.

CHECKING MANIFOLD ABSOLUTE PRESSURE SENSOR

1. Connect:
 - FI Diagnostic Tool “1”

	FI Diagnostic Tool: 90890-03253
--	--

2. Select Mode:
 - Select “DIAG” Mode and “MAP” Diag Code.

3. Check:
 - Compare “MAP” value with atmosphere pressure

	Atmosphere pressure (Reference): 14–15 Psi
--	---

Does not much → Replace the manifold absolute.

CHECKING THE THROTTLE POSITION SENSOR

1. Remove:
 - Throttle body assembly
(Refer to “THROTTLE BODY ASSEMBLY” on page 4-6)

NOTICE

- Handle the throttle body assembly with special care.
- Never subject the throttle body assembly to strong shocks. If the throttle body assembly is dropped, replace it.

2. Check:
 - Throttle position sensor maximum resistance
Out of specification → Replace the throttle position sensor.

	Resistance: 3.0–7.0 kΩ
---	---



a. Connect the digital circuit tester (Ω) to the throttle position sensor terminals as shown.

	Model 88 Multimeter with tachometer: YU-A1927
---	--

- Positive tester probe → Terminal “a”
- Negative tester probe → Terminal “b”

b. Measure the throttle position sensor maximum resistance.



- 3.** Install:
- Throttle body assembly

CHECKING THE CRANKSHAFT POSITION SENSOR


- 1.** Remove:
- Fan case cover
 - Grass screen
 - Fan case
- (Refer to “CASE AND FAN” on page 3-11)
- 2.** Check:
- Crankshaft position sensor resistance
- Out of specification → Replace the crankshaft position sensor.


	Crankshaft position sensor resistance: 3.0–7.0 kΩ
---	--



a. Connect the digital circuit tester (Ω) to the crankshaft position sensor coupler as shown.

	Model 88 Multimeter with tachometer: YU-A1927
---	--





- Positive tester probe → White/Red “1” (wire harness color)
- Negative tester probe → Black “2” (wire harness color)

b. Measure the crankshaft position sensor resistance.



CHECKING THE ENGINE TEMPERATURE SENSOR

1. Remove:
 - Engine temperature sensor

WARNING

- Handle the engine temperature sensor with special care.
- Never subject the engine temperature sensor to strong shocks. If the engine temperature sensor is dropped, replace it.

NOTICE

Use inch tool “5/8” or 16 mm for engine temperature sensor.

2. Check:
 - Engine temperature sensor resistance
 - Out of specification → Replace.


	Engine temperature sensor resistance: 9.0–11.0 kΩ at 25 °C (77 °F)
--	--



a. Connect the digital circuit tester (Ω) to the engine temperature sensor as shown.

	Model 88 Multimeter with tachometer: YU-A1927
--	---

b. Immerse the engine temperature sensor “1” in a container filled with water “2”.



TIP

Make sure the engine temperature sensor terminals do not get wet.

- c. Place a thermometer “3” in the water.
- d. Slowly heat the water, then let it cool down to the specified temperature.

- e. Measure the engine temperature sensor resistance.




- 3.** Install:
 - Engine temperature sensor

CHECKING THE IGNITION COILS


The following procedure applies to all of the ignition coils.

- 1.** Check:
 - Primary coil resistance
 Out of specification → Replace.

	Primary coil resistance: 0.44–0.66 Ω
---	--



- a. Remove the ignition coil from the spark plug.
- b. Connect the digital circuit tester (Ω) to the ignition coil as shown.



	Model 88 Multimeter with tachometer: YU-A1927
--	---

<ul style="list-style-type: none"> • Positive tester probe → Red “1” (wire harness color) • Negative tester probe → Black “2” (wire harness color)
--

- c. Measure the primary coil resistance.





- 2.** Check:
 - Secondary coil resistance
 Out of specification → Replace.

	Secondary coil resistance: 5.6–8.4 kΩ
---	---



- a. Connect the digital circuit tester (Ω) to the ignition coil as shown.

	Model 88 Multimeter with tachometer: YU-A1927
---	---



- Positive tester probe → Red “1” (wire harness color)
- Negative tester probe → High-tension cord “2”

b. Measure the secondary coil resistance.



CHECKING THE IGNITION SPARK GAP

The following procedure applies to all of the ignition coils.

1. Check:
 - Ignition spark gap
Out of specification → Perform the ignition system troubleshooting, starting with step 5.
(Refer to “IGNITION SYSTEM” on page 6-1)




Minimum ignition spark gap:
6.0 mm (0.236 in)

TIP

If the ignition spark gap is within specification, the ignition system circuit is operating normally.



- a. Disconnect the spark plug cap “1” from the spark plug.
- b. Connect the ignition checker “2” as shown.



Ignition checker:
90890-06754

- c. Turn the main switch to “START”.
- d. Measure the ignition spark gap “a”.




CHECKING THE SPARK PLUG CAPS

The following procedure applies to all of the spark plug caps.

1. Remove:
 - Spark plug cap
2. Check:
 - Spark plug cap resistance
Out of specification → Replace the spark plug cap.



Spark plug cap resistance:
3.75–6.25 kΩ



- a. Remove the spark plug cap from the high tension cord.
- b. Connect the digital circuit tester (Ω) to the spark plug cap as shown.

	Model 88 Multimeter with tachometer: YU-A1927
--	--

- Positive tester probe → Spark plug side “1”
- Negative tester probe → High tension cord side “2”

- c. Measure the spark plug cap resistance.

CHECKING THE STATOR COIL ASSEMBLY

1. Disconnect:
 - Stator coil connector (from the wire harness)
2. Check:
 - Stator coil resistance
Out of specification → Replace the stator coil assembly.


	Stator coil resistance: 18 A: 0.16–0.24 Ω at 23 °C (73.4 °F) 20 A: 0.112–0.168 Ω at 23 °C (73.4 °F) 25 A: 0.096–0.144 Ω at 23 °C (73.4 °F)
--	---

- a. Connect the digital circuit tester to the stator coil connector as shown.

	Model 88 Multimeter with tachometer: YU-A1927
--	--

- Positive tester probe → White
- Negative tester probe → White

- b. Measure the stator coil resistance.




CHECKING THE RECTIFIER/REGULATOR

- 1.** Check:
 - Rectifier/regulator output voltage
Out of specification → Replace the rectifier/regulator.

	Regulated voltage: 14–15 V
---	---



- a. Connect FI Diagnostic Tool.
- b. Connect the digital circuit tester (DC) to the rectifier/regulator harness.

	FI Diagnostic Tool: 90890-03253 Model 88 Multimeter with tachometer: YU-A1927
---	--

- | |
|---|
| <ul style="list-style-type: none">• Positive tester probe →
Red (wire harness color)• Negative tester probe →
Black (wire harness color) |
|---|

- c. Start the engine.
- d. Measure the regulated voltage.



CHECKING THE FUEL INJECTORS

The following procedure applies to all of the fuel injectors.


- 1.** Remove:
 - Fuel injector
(Refer to “FUEL INJECTORS AND INTAKE MANIFOLD” on page 4-9)
- 2.** Check:
 - Fuel injector resistance
Out of specification → Replace the fuel injector.

	Resistance: 11.4–12.6 Ω
---	--



- a. Disconnect the fuel injector coupler from the fuel injector.
- b. Connect the digital circuit tester (Ω) to the fuel injector coupler as shown.

	Model 88 Multimeter with tachometer: YU-A1927
---	--



- Positive tester probe → Injector terminal “1”
- Negative tester probe → Injector terminal “2”

c. Measure the fuel injector resistance.




CHECKING THE STARTER MOTOR OPERATION

1. Check:

- Starter motor operation
Does not operate → Perform the electric starting system troubleshooting, starting with step 4.
(Refer to “ELECTRIC STARTING SYSTEM” on page 6-2)




a. Connect the jumper lead “1” to the starter relay terminals on the battery side and the starter motor side.



WARNING

- A wire that is used as a jumper lead must have at least the same capacity of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore, make sure no flammable gas or fluid is in the vicinity.

- b. Check the starter motor operation.
- c. Disconnect the main switch coupler.
- d. Connect the jumper lead “1” to the starter relay coupler.
- e. Check the starter motor operation.




ELECTRIC STARTING SYSTEM

ELECTRIC STARTING SYSTEM

REMOVING THE STARTER MOTOR

5


ELECTRICAL



Order	Job/Parts to remove	Q'ty	Remarks
	Removing the starter motor		Remove the parts in the order listed.
1	Starter relay terminals	1	Disconnect.
2	Earth terminal	1	Disconnect.
3	Starter motor assembly	1	

ELECTRIC STARTING SYSTEM

DISASSEMBLING THE STARTER MOTOR



5
ELECTRICAL

Order	Job/Parts to remove	Q'ty	Remarks
	Disassembling the starter motor		Disassemble the parts in the order listed.
1	Rear bracket	1	
2	Insulator	1	
3	Brush spring	4	
4	Brush	4	
5	Yoke	1	
6	Armature	1	
7	Starter relay	1	
8	Starter drive lever	1	
9	Starter case	1	

CHECKING THE ARMATURE COIL

1. Check:
 - Commutator (outer surface)
Dirty → Clean it with #600 grit sandpaper.
2. Measure:
 - Mica (insulation depth between the commutator segments)
Out of specification → Scrape the mica to the proper measurement using a hacksaw blade which has been grounded to fit the commutator.



	Depth of insulator “a”: 2.0 mm (0.79 in)
--	---


TIP

The mica insulation of the commutator must be undercut to ensure proper operation of the commutator.


3. Measure:
 - Armature coil (insulation/continuity)
Defects → Replace the starter motor.
Connect the digital circuit tester to the armature coil.

	Model 88 Multimeter with tachometer: YU-A1927
--	--

	Commutator continuity: Continuity Insulation resistance: More than 1.0 MΩ
--	--




1. Continuity check
2. Insulation check
3. Armature coil



CHECKING THE BRUSH

- 1.** Measure:
 - Brush length (of each brush) “1”
 - Out of specification → Replace.

	Brush wear limit length: 6.0 mm (0.2362 in)
---	--


- 2.** Check:
 - Brush spring “2”
 - Fatigue/damage → Replace.


CHECKING THE STARTER RELAY

- 1.** Measure:
 - Magnetic switch coil resistance
 - Connect the digital circuit tester (Ω) to the magnetic switch.

	Model 88 Multimeter with tachometer: YU-A1927
--	--


Out of specification → Replace.




	Holding coil resistance A–B: 0.88–1.32 Ω Pull-in coil resistance A–C: 0.4–0.6 Ω
---	--

ASSEMBLING THE STARTER MOTOR


- 1.** Install:
 - Starter drive lever “1”




ELECTRIC STARTING SYSTEM



- 2.** Install:
- Armature and starter drive lever “1”



- 3.** Install:
- Starter relay “1”

	Starter relay nut: 11 N·m (1.1 kgf·m, 8.0 lb·ft)
---	---

5

ELECTRICAL

TROUBLESHOOTING

ENGINE DOES NOT START

IGNITION SYSTEM

The ignition system fails to operate (no spark or intermittent spark).

No.	Checking steps	Possible remedy
1	Check the fuses. (Refer to "CHECKING THE FUSES" on page 5-27)	Replace the fuse(s).
2	Check the battery.	<ul style="list-style-type: none">• Clean the battery terminals.• Recharge or replace the battery.
3	Check the spark plugs. (Refer to "SPARK PLUGS" on page 2-2).	Re-gap or replace the spark plugs.
4	Check the ignition spark gap. (Refer to "CHECKING THE IGNITION SPARK GAP" on page 5-33)	If the ignition spark gap is OK, the ignition system is OK.
5	Check the ignition coils. (Refer to "CHECKING THE IGNITION COILS" on page 5-32)	Replace the ignition coils.
6	Check the spark plug cap resistance. (Refer to "CHECKING THE SPARK PLUG CAPS" on page 5-33).	Replace the spark plug cap.
7	Check the crankshaft position sensor. (Refer to "CHECKING THE CRANKSHAFT POSITION SENSOR" on page 5-30)	Replace the crankshaft position sensor.
8	Check the main switch.	Replace the main switch.
9	Check the entire ignition system's wiring. (Refer to "CIRCUIT DIAGRAM" on page 5-1)	Properly connect or repair the ignition system's wiring.
10	Replace the ECU.	—

ENGINE DOES NOT START

ELECTRIC STARTING SYSTEM

The starter motor fails to turn.

No.	Checking steps	Possible remedy
1	Check the fuses. (Refer to "CHECKING THE FUSES" on page 5-27)	Replace the fuse(s).
2	Check the battery.	<ul style="list-style-type: none">• Clean the battery terminals.• Recharge or replace the battery.
3	Check the starter motor operation. (Refer to "CHECKING THE STARTER MOTOR OPERATION" on page 5-36)	If the starter motor operates normally, the starter motor is OK.
4	Check the starter motor. (Refer to "ELECTRIC STARTING SYSTEM" on page 5-37)	Repair or replace the starter motor.
5	Check the main switch.	Replace the main switch.
6	Check the entire starting system's wiring. (Refer to "CIRCUIT DIAGRAM" on page 5-1)	Properly connect or repair the starting system's wiring.
7	The starting system circuit is OK.	—

FUEL INJECTION SYSTEM

(Refer to "FUEL INJECTION SYSTEM" on page 5-3)

FUEL PUMP SYSTEM

If the high-pressure fuel pump fails to operate.

No.	Checking steps	Possible remedy
1	Check the fuses. (Refer to "CHECKING THE FUSES" on page 5-27)	Replace the fuse(s).
2	Check the battery.	<ul style="list-style-type: none">• Clean the battery terminals.• Recharge or replace the battery.
3	Check the main switch.	Replace the main switch.
4	Check the fuel pumps. (Refer to "FUEL PUMPS" on page 4-1)	Replace the fuel pumps.
5	Check the entire high-pressure fuel pump system's wiring. (Refer to "CIRCUIT DIAGRAM" on page 5-1)	Properly connect or repair the high-pressure fuel pump system's wiring.
6	Replace the ECU.	—

OTHER TROUBLES

OTHER TROUBLES

ENGINE STARTS BUT STALLS

No.	Checking steps	Possible remedy
1	Check the fuel level.	Add the fuel if it is insufficient.
2	Check if the fuel filter is clogged.	Clean or replace.
3	Check if the fuel hoses is clogged.	Clean.
4	Check if there is air suction from the throttle body assembly joint, gasket, or throttle shaft.	<ul style="list-style-type: none">• Tighten the throttle body assembly nuts securely.• Replace the throttle body assembly joint or gasket with a new one.
5	Check the fuel pumps. (Refer to "FUEL PUMPS" on page 4-1)	Replace the fuel pumps.
6	Check the low engine speed. (Refer to "ENGINE SPEED" on page 2-14)	Adjust the low engine speed.
7	Measure the valve clearance. (Refer to "ADJUSTING THE VALVE CLEARANCE" on page 2-9)	Adjust the valve clearance.
8	Check the compression pressure. (Refer to "MEASURING THE COMPRESSION PRESSURE" on page 3-1)	Too high: Decarbonize the combustion chamber if there is carbon deposits. Too low: Next checking steps.
9	Check if there is seizure, wear, or damage on the piston, piston ring, or cylinder. (Refer to "PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT" on page 3-38)	Rebore or replace.
10	Check the crankshaft position sensor air gap. (Refer to "INSTALLING THE CRANKSHAFT POSITION SENSOR" on page 3-19)	Adjust.

OTHER TROUBLES

ENGINE SPEED DOES NOT INCREASE

No.	Checking steps	Possible remedy
1	Check the spark plugs for dirt and check the spark plug gap.	Clean, adjust, or replace the spark plugs.
2	Check the air filter element for dirt.	Replace the air filter element.
3	Check spark arrester, muffler and air filter.	Clean or replace spark arrester, muffler and air filter.
4	Check the valve clearance. (Refer to "ADJUSTING THE VALVE CLEARANCE" on page 2-9)	Adjust the valve clearance.
5	Check the compression pressure. (Refer to "MEASURING THE COMPRESSION PRESSURE" on page 3-1)	Too high: Decarbonize the combustion chamber if there is carbon deposits. Too low: Next checking steps.
6	Check governor setting. (Refer to "INSTALLING THE THROTTLE BODY ASSEMBLY" on page 4-7)	Adjust the governor.
7	Check the valve face and valve seat for wear. (Refer to "VALVES" on page 3-27)	Resurface or replace the valve face and valve seat.
8	Check if the marks on the crankshaft and camshaft are aligned. (Refer to "INSTALLING THE VALVE LIFTERS AND CAMSHAFT" on page 3-45)	Correct.
9	Check if there is seizure, wear, or damage on the piston, piston ring, or cylinder. (Refer to "PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT" on page 3-38)	Rebore or replace.
10	Check if the main passages, such as the throttle body assembly, are clogged.	Clean the parts.
11	Check if there is air suction from the throttle body assembly joint, gasket, or throttle shaft.	<ul style="list-style-type: none"> • Tighten the throttle body assembly nuts securely. • Replace the throttle body assembly joint or gasket with a new one.

OTHER TROUBLES

ENGINE SPEED IS UNEVEN

No.	Checking steps	Possible remedy
1	Check the fuel level.	Add the fuel if it is insufficient.
2	Check if fuel has deteriorated.	Replace the fuel.
3	Check the spark plugs for dirt and check the spark plug gap.	Clean, adjust, or replace the spark plugs.
4	Check if there is air suction from the throttle body assembly joint, gasket, or throttle shaft.	<ul style="list-style-type: none"> • Tighten the throttle body assembly nuts securely. • Replace the throttle body assembly joint or gasket with a new one.
5	Check if the main passages, such as the throttle body assembly, are clogged.	Clean the parts.
6	Check the valve clearance. (Refer to "ADJUSTING THE VALVE CLEARANCE" on page 2-9)	Adjust the valve clearance.
7	Check the valve face and valve seat for wear. (Refer to "VALVES" on page 3-27)	Resurface or replace the valve face and valve seat.
8	Check if there is seizure, wear, or damage on the piston, piston ring, or cylinder. (Refer to "PISTONS, CAMSHAFT, CRANKCASE, AND CRANKSHAFT" on page 3-38)	Rebore or replace the piston, piston ring or cylinder.

THE BATTERY IS NOT CHARGED

No.	Checking steps	Possible remedy
1	Check the fuses. (Refer to "CHECKING THE FUSES" on page 5-27)	Replace the fuse(s).
2	Check the battery.	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
3	Check the stator coil. (Refer to "CHECKING THE STATOR COIL ASSEMBLY" on page 5-34)	Replace the stator coil assembly.
4	Check the rectifier/regulator. (Refer to "CHECKING THE RECTIFIER/REGULATOR" on page 5-35)	Replace the rectifier/regulator.
5	Check the entire charging system's wiring. (Refer to "CIRCUIT DIAGRAM" on page 5-1)	Properly connect or repair the charging system's wiring.
6	The charging system circuit is OK.	—

OIL PRESSURE SYSTEM

GOVERNOR OPERATION

No.	Checking steps	Possible remedy
1	Check that the governor link operate smoothly.	Adjust or replace.
2	Check that the governor spring is stretched.	Replace.
3	Check the governor adjustment. (Refer to "INSTALLING THE THROTTLE BODY ASSEMBLY" on page 4-7)	Adjust.
4	Check the governor weight and governor bushing function. (Refer to "CHECKING THE FLYWEIGHT SHAFT ASSEMBLY" on page 3-41)	Adjust or replace.

6

TROUBLESHOOTING

OIL PRESSURE SYSTEM

If the oil pressure switch fails to operate.

No.	Checking steps	Possible remedy
1	Check the fuses. (Refer to "CHECKING THE FUSES" on page 5-27)	Replace the fuse(s).
2	Check the battery.	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
3	Check the main switch.	Replace the main switch.
4	Check the engine oil level.	Add the oil if it is insufficient.
5	Check the oil filter.	Replace the oil filter.
6	Check the oil pressure switch. (Refer to "CHECKING THE OIL PRESSURE SWITCH" on page 5-28)	Replace the oil pressure switch.
7	Check the entire oil pressure system's wiring. (Refer to "CIRCUIT DIAGRAM" on page 5-1)	Properly connect or repair the oil pressure system's wiring.
8	Check the oil pump. (Refer to "CHECKING THE OIL PUMP" on page 3-34)	Replace the oil pump.
9	Check the relief valve. (Refer to "CHECKING THE RELIEF VALVE" on page 3-35)	Replace the relief valve.
10	Replace the ECU.	—

SPECIFICATIONS

GENERAL SPECIFICATIONS

Model:

MX775 (7U2J)
MX800 (7U1J)
MX825 (7UDJ)

Dimensions:

Overall length 499 mm (19.65 in)
Overall width 463 mm (18.23 in)
Overall height 639 mm (25.16 in)
Dry weight 60 kg (132 lb)

Engine:

Engine type Air cooled 4-stroke gasoline OHV
Cylinder arrangement V-type 2-cylinder
Displacement 0.824 L (824 cm³)
Bore × Stroke 80.0 × 82.0 mm (3.15 × 3.23 in)
Compression ratio 9.1
Standard compression pressure 1.31–1.45 MPa (13.4–14.8 kg/cm², 190–210 psi)
Limit 150 psi
Fuel Unleaded gasoline (Gasohol [E10] acceptable)*
Engine oil quantity 2.0 L (2.11 US qt, 1.76 Imp.qt)
Recommended engine oil YAMALUBE SAE 10W-30 Performance All Purpose, SAE 10W-30 or 10W-40
Recommended engine oil grade API Service SE type or higher
Oil filter type Cartridge
Lubrication system Full pressure with filter
Air filter system Dry
Cooling system Air cooled
Starting system Electric starter
Stopping system Misfire
Rotating direction Counterclockwise (From PTO shaft)
Governor type Centrifugal weight system
Maximum angle of operation 30° (Low oil level)

Electrical:

Ignition system ECU control battery ignition
Ignition timing BTDC 30°/ 3750 r/min
Spark plug type BPR6ES (NGK)
Spark plug gap 0.7–0.8 mm (0.028–0.031 in)
Fuse amperage 30 A × 1
10 A × 2

GENERAL SPECIFICATIONS

* Yamaha engine has been designed to use regular unleaded gasoline with a pump octane number ((R+M)/2) of 86 or higher, or research octane number of 91 or higher.
Gasohol containing ethanol can be used if the ethanol content does not exceed 10 % (E10).

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts.

MAINTENANCE SPECIFICATIONS

MAINTENANCE SPECIFICATIONS

ENGINE

Piston:

Piston-to-cylinder clearance	0.033–0.047 mm (0.0013–0.0019 in)
Limit	0.15 mm (0.0059 in)
Piston diameter	79.959–79.980 mm (3.1480–3.1488 in)
Limit	79.900 mm (3.1457 in)
Measuring point (from piston skirt bottom)	6.0 mm (0.2362 in)
Oversize 1st	80.25 mm (3.1594 in)
2nd	80.50 mm (3.1693 in)
Piston pin hole inside diameter	19.004–19.015 mm (0.7482–0.7486 in)
Limit	19.045 mm (0.7498 in)

Piston pin:

Piston pin diameter	18.995–19.000 mm (0.7478–0.7480 in)
Limit	18.975 mm (0.7470 in)

Piston ring:

Top ring	
Type	Barrel
Dimensions	1.2 × 2.9 mm (0.0472 × 0.1142 in)
End gap (installed)	0.20–0.35 mm (0.0079–0.0138 in)
Limit	0.60 mm (0.0236 in)
Side clearance	0.04–0.08 mm (0.0016–0.0031 in)
Limit	0.13 mm (0.0051 in)
2nd ring	
Type	Taper
Dimensions	1.0 × 2.5 mm (0.0394 × 0.0984 in)
End gap (installed)	0.20–0.35 mm (0.0079–0.0138 in)
Limit	0.60 mm (0.0236 in)
Side clearance	0.03–0.07 mm (0.0012–0.0028 in)
Limit	0.13 mm (0.0051 in)
Oil ring	
Type	3-piece type
Dimensions	2.0 × 2.5 mm (0.0787 × 0.0984 in)
End gap (installed)	0.20–0.70 mm (0.0079–0.0276 in)

Cylinder head:

Warpage limit	0.05 mm (0.002 in)
---------------	--------------------

Cylinder:

Bore	80.000–80.020 mm (3.1496–3.1504 in)
Warpage limit	80.025 mm (3.1506 in)

MAINTENANCE SPECIFICATIONS

Crankshaft:

Big end side clearance	0.20–0.65 mm (0.0079–0.0256 in)
Runout limit	0.03 mm (0.0012 in)
Crank pin outside diameter	40.950–41.050 mm (1.6122–1.6161 in)

Connecting rod:

Small end diameter	19.006–19.020 mm (0.7483–0.7488 in)
Oil clearance	0.006–0.025 mm (0.0002–0.0010 in)
Big end diameter	40.005–40.020 mm (1.5750–1.5756 in)
Oil clearance	0.016–0.046 mm (0.0006–0.0018 in)
Limit	0.09 mm (0.0035 in)

Camshaft:

Camshaft lobe dimensions	
Lobe height (Intake)	32.885 mm (1.2947 in)
Limit	32.785 mm (1.2907 in)
Lobe height (Exhaust)	33.957 mm (1.3369 in)
Limit	33.857 mm (1.3330 in)
Base circle diameter (Intake)	26.000 mm (1.0236 in)
Limit	25.900 mm (1.0197 in)
Base circle diameter (Exhaust)	26.000 mm (1.0236 in)
Limit	25.900 mm (1.0197 in)
Camshaft journal diameter	16.965–16.990 mm (0.6679–0.6689 in)
Limit	16.950 mm (0.6673 in)

Valve:

Valve dimensions	
Valve head diameter (Intake)	27.9–28.1 mm (1.0984–1.1063 in)
Valve head diameter (Exhaust)	34.9–35.1 mm (1.3740–1.3819 in)
Valve stem diameter (Intake)	5.948–5.963 mm (0.2342–0.2348 in)
Valve stem diameter (Exhaust)	5.940–5.955 mm (0.2339–0.2344 in)
Limit (Intake)	5.918 mm (0.2330 in)
Limit (Exhaust)	5.910 mm (0.2327 in)
Valve stem length (Intake)	88.8 mm (3.4961 in)
Valve stem length (Exhaust)	89.8 mm (3.5354 in)
Valve face contact width (Intake)	0.9–1.1 mm (0.0354–0.0433 in)
Valve face contact width (Exhaust)	0.9–1.1 mm (0.0354–0.0433 in)
Limit (Intake)	1.6 mm (0.063 in)
Limit (Exhaust)	1.6 mm (0.063 in)
Valve seat contact width (Intake)	0.9–1.1 mm (0.0354–0.0433 in)
Valve seat contact width (Exhaust)	0.9–1.1 mm (0.0354–0.0433 in)

MAINTENANCE SPECIFICATIONS

Limit (Intake)	1.6 mm (0.063 in)
Limit (Exhaust)	1.6 mm (0.063 in)
Valve stem runout limit	0.01 mm (0.0004 in)

Valve guide

Guide inside diameter (Intake)	6.000–6.012 mm (0.2362–0.2367 in)
Guide inside diameter (Exhaust)	6.000–6.012 mm (0.2362–0.2367 in)
Stem to guide clearance (Intake)	0.08 mm (0.0031 in)
Stem to guide clearance (Exhaust)	0.10 mm (0.0039 in)
Valve clearance (cold)	
Intake	0.02–0.2 mm (0.0008–0.01 in)
Exhaust	0.02–0.2 mm (0.0008–0.01 in)

Push rod:

Runout limit	0.3 mm (0.0118 in)
--------------	--------------------

Rocker arm:

Rocker arm shaft hole inside diameter (Intake)	12.000–12.018 mm (0.4724–0.4731 in)
Rocker arm shaft hole inside diameter (Exhaust)	12.000–12.018 mm (0.4724–0.4731 in)
Rocker arm shaft diameter (Intake)	11.981–11.991 mm (0.4717–0.4721 in)
Rocker arm shaft diameter (Exhaust)	11.981–11.991 mm (0.4717–0.4721 in)
Oil clearance	0.08 mm (0.0031 in)

Valve spring:

Valve spring free length (Intake)	37.1 mm (1.4606 in)
Valve spring free length (Exhaust)	35.6 mm (1.4016 in)
Limit (Intake)	35.25 mm (1.3878 in)
Limit (Exhaust)	33.82 mm (1.3315 in)
Installed length (Intake)	29.3 mm (1.1535 in)
Installed length (Exhaust)	29.0 mm (1.1417 in)
Installed compression spring force (Intake)	67.7 N (6.90 kgf, 15.2 lbf)
Installed compression spring force (Exhaust)	118.1 N (12.0 kgf, 26.5 lbf)
Tilt limit	2.0 mm (0.0787 in)

Fuel pump:

Pump type (Lo)	Mechanical
Pump type (Hi)	Electrical

MAINTENANCE SPECIFICATIONS

Fuel line pressure (at idle) 255–285 kPa (2.55–2.85 kgf/cm², 36.98–41.33 psi)

Fuel injector:

Resistance 11.4–12.6 Ω

Oil pump:

Inner-rotor-to-outer-rotor-tip clearance 0.19–0.35 mm (0.008–0.013 in)

Relief valve operating pressure 342–538 kPa (3.42–5.38 kgf/cm², 49.59–78.01 psi)

Throttle body:

ID mark E-3750-2 (MX775)
E-3750-1 (MX800)
E-3750-0 (MX825)

Throttle position sensor:

Output voltage (at idle) 0.95–4.5 V

Resistance 3.0–7.0 kΩ

Governor assembly:

Tension spring attach hole 7

Engine speed:

High engine speed (with no load) 3550–3600 r/min

Low engine speed (with no load) 1450–1550 r/min

MAINTENANCE SPECIFICATIONS

ELECTRICAL

Ignition coil:

Primary coil resistance	0.44–0.66 Ω
Secondary coil resistance	5.6–8.4 k Ω
Spark plug cap resistance	3.75–6.25 k Ω
Crankshaft position sensor air gap	0.5–1.5 mm (0.02–0.06 in)
Minimum ignition spark gap	6.0 mm (0.236 in)

Charging system:

Standard output at 3600 r/min	18 A: More than 18 A 20 A: More than 20 A 25 A: More than 25 A
Stator coil resistance	18 A: 0.16–0.24 Ω at 23 °C (73.4 °F) 20 A: 0.112–0.168 Ω at 23 °C (73.4 °F) 25 A: 0.096–0.144 Ω at 23 °C (73.4 °F)

Rectifier/regulator:

Regulator type	Single-phase full-wave rectification
Regulated voltage	14–15 V
Rectifier capacity	25 A

Fuel injection sensor:

Crankshaft position sensor resistance	3.0–7.0 k Ω
Manifold absolute pressure sensor air pressure	14–15 psi
Engine temperature sensor resistance	9.0–11.0 k Ω at 25 °C (77 °F)

Electric starting system:

Depth of insulator	2.0 mm (0.79 in)
Insulation resistance	More than 1.0 M Ω
Brush spring pressure	11.73–15.35 N (1.196–1.565 kgf, 2.637–3.451 lbf)
Brush wear limit length	6.0 mm (0.2362 in)
Holding coil resistance	0.88–1.32 Ω
Pull-in coil resistance	0.4–0.6 Ω

TIGHTENING TORQUES

TIGHTENING TORQUES

Item	Thread size	Tightening torque
Spark plug	M14S × 1.25	20 N·m (2.0 kgf·m, 14 lb·ft)
Spark arrester screw	—	3.5 N·m (0.35 kgf·m, 2.5 lb·ft)
Oil filter	—	14 N·m (1.4 kgf·m, 10 lb·ft)
Oil drain bolt	M12 × 1.5	27 N·m (2.7 kgf·m, 20 lb·ft)
Air filter case stay bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Air filter case stay bolt	M8 × 1.25	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Joint 2 clamp bolt	—	1.8 N·m (0.18 kgf·m, 1.3 lb·ft)
ECU bolt	M5 × 0.8	4.0 N·m (0.40 kgf·m, 2.9 lb·ft)
Rectifier/regulator bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Engine hunger bolt	M8 × 1.25	20 N·m (2.0 kgf·m, 14 lb·ft)
Engine hunger bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Fuse holder bracket bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Ignition coil bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
O ₂ sensor	M12 × 1.25	18 N·m (1.8 kgf·m, 13 lb·ft)
Muffler nut	—	20 N·m (2.0 kgf·m, 14 lb·ft)
Adapter union bolt	M20 × 1.5	62 N·m (6.2 kgf·m, 45 lb·ft)
Oil cooler bolt	M6 × 1.0	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Fan bolt	M6 × 1.0	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Fan case bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Grass screen bolt	M6 × 1.0	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Fan case cover bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Oil filler pipe bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Stator coil assembly bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Flywheel nut	M22 × 1.5	180 N·m (18 kgf·m, 130 lb·ft)
Crankshaft position sensor bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Cylinder air shroud bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Cylinder head cover bolt	M6 × 1.0	11 N·m (1.1 kgf·m, 8.0 lb·ft)
Rocker arm shaft bolt	M5 × 1.0	4.0 N·m (0.40 kgf·m, 2.9 lb·ft)
Cylinder head bolt	M10 × 1.25	1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft) 2nd: 50 N·m (5.0 kgf·m, 36 lb·ft)
Oil pressure switch	M4 × 0.7	8 N·m (0.8 kgf·m, 5.8 lb·ft)
Oil pump cover bolt	M6 × 1.0	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Relief valve	M12 × 1.25	30 N·m (3.0 kgf·m, 22 lb·ft)
Crankcase cover 2 bolt	M8 × 1.25	1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft) 2nd: 30 N·m (3.0 kgf·m, 22 lb·ft)
Cover 1 bolt	M6 × 1.0	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Cover 2 bolt	M6 × 1.0	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Crankcase cover 1 bolt	M8 × 1.25	1st: 12 N·m (1.2 kgf·m, 8.7 lb·ft) 2nd: 30 N·m (3.0 kgf·m, 22 lb·ft)
Connecting rod cap bolt	M8 × 1.25	20 N·m (2.0 kgf·m, 14 lb·ft)

TIGHTENING TORQUES

Item	Thread size	Tightening torque
Engine temperature sensor	M10 × 1.5	12 N·m (1.2 kgf·m, 8.7 lb·ft)
Reed valve	M6 × 1.0	10 N·m (1.0 kgf·m, 7.2 lb·ft)
Scroll air shroud bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Low-pressure fuel pump bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
High-pressure fuel pump bolt	M6 × 1.0	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Fuel pump bracket	M6 × 1.0	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Throttle body assembly nut	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Governor assembly bolt	M6 × 1.0	8 N·m (0.8 kgf·m, 5.8 lb·ft)
Inlet pipe bolt	M6 × 1.0	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Manifold absolute pressure sensor bolt	M6 × 1.0	7 N·m (0.7 kgf·m, 5.1 lb·ft)
Intake manifold nut and bolt	M6 × 1.0	1st: 3.0 N·m (0.30 kgf·m, 2.2 lb·ft) 2nd: 7 N·m (0.7 kgf·m, 5.1 lb·ft)
Starter motor assembly bolt	M8 × 1.25	23 N·m (2.3 kgf·m, 17 lb·ft)
Earth terminal nut	M8 × 1.25	9 N·m (0.9 kgf·m, 6.5 lb·ft)
Starter motor rear bracket bolt	M6 × 0.8	6 N·m (0.6 kgf·m, 4.3 lb·ft)
Starter relay nut	M6 × 1.0	11 N·m (1.1 kgf·m, 8.0 lb·ft)

GENERAL TORQUE SPECIFICATIONS



























GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specifications call for clean, dry threads. Components should be at room temperature.

Thread size	Tightening torque		
	N·m	kgf·m	lb·ft
M4	2	0.2	1.5
M5	3	0.3	2.2
M6	7	0.7	5.2
M7	10	1.0	7.4
M8	15	1.5	11.1
M10	30	3.0	22.1
M12	60	6.0	44.3

LUBRICATION POINTS AND TYPE OF LUBRICANTS


LUBRICATION POINTS AND TYPE OF LUBRICANTS

Part name	Type of lubricant
Oil seal lip	
Oil hose 1, 2	
Governor fork oil seal lip	
Bearing	
Connecting rod big end	
Crank pin	
Crankshaft journal	
Connecting rod cap bolt	
Piston pin	
Piston	
Valve stem	
Valve stem end	
Valve rocker arm shaft	
Valve push rod end	
Valve lifter stem	
Camshaft lobe	
Camshaft gear teeth	
Camshaft journal	
Adjusting pad	
Inner rotor	
Outer rotor	
Fuel injector O-ring	
Governor collar internal surface	
Governor fork meet surface	
Governor weight moving point	
Oil pressure switch	
Crankcase cover 2	Three bond No. 1217G®
Cover 1	Three bond No. 1217G®

WIRE ROUTING DIAGRAM

WIRE ROUTING DIAGRAM

UPPER SIDE VIEW



7

SPECIFICATIONS


WIRE ROUTING DIAGRAM

1. Hose clamp
 2. Inlet pipe 2
 3. Fuel injector #2
 4. Fuel injector pipe 2
 5. Fuel injector #1
 6. Inlet pipe 1
 7. High-pressure fuel pump
 8. Wire harness
 9. Purge hose 2
 10. 3 WAY joint
 11. Purge hose 1
 12. Plastic locking tie
 13. Fuel injector pipe 1
- A. Fuel injector pipe 1 connector installation details
 - Insert the fuel injector pipe 1 connector until a click is heard, and then make sure that the connector is not disconnected.
 - When inserting the fuel injector pipe 1 connector, pay attention not to prize.
 - B. Insert the purge hose 1, purge hose 2, cap all the way into the 3 WAY joint.
 - C. Make sure that there is no looseness or tension of the lead.
 - D. Insert the protector side of the purge hose 2 all the way into the pipe of the fuel pump.
 - E. Install the cap in the direction shown in the illustration.
 - F. Keep the length shown in the illustration to 0–2.0 mm (0–0.08 in) and cut off the end of the plastic locking tie.
 - G. The binding area of the plastic locking tie should be on the outside of the engine.
 - H. 2.0–4.0 mm (0.08–0.16 in)
 - I. Insert the fuel injector pipes until it contacts the inlet pipes.
 - J. Install the yellow painted portion in the direction shown in the illustration.
 - K. Install the white painted portion in the direction shown in the illustration.

WIRE ROUTING DIAGRAM

7

SPECIFICATIONS




WIRE ROUTING DIAGRAM

1. Crankshaft position sensor
 2. Ignition coil #2
 3. Throttle position sensor lead
 4. Engine temperature sensor lead
 5. O₂ sensor lead
 6. Ignition coil #1 coupler
 7. Fuel injector #1 coupler
 8. Ignition coil #1
 9. Wire harness
 10. Stator
 11. Crankshaft position sensor coupler
 12. Fuel injector #2 coupler
 13. Manifold absolute pressure sensor lead
 14. Ignition coil #2 coupler
 15. Fuel injector #1 lead
 16. Ignition coil #1 lead
 17. Plastic locking tie
 18. Fuel injector #2 and crankshaft position sensor lead
 19. High-pressure fuel pump lead and oil pressure switch lead
 20. Ignition coil #2 lead
 21. Fuel injector #2 lead
 22. Intake manifold
- A. Install the leads so that they overlap each other.
 - B. Lock the fuel injector coupler after installation.
 - C. Install the lead as shown in the illustration.
 - D. Gap between crankshaft position sensor and rotor should be 0.5–1.5 mm (0.02–0.06 in).
 - E. Installation details of ignition coil and coupler
 - F. After installing the coupler, insert it until it is locked.
 - G. Boss
 - H. Align the wire harness with the boss of the intake manifold.
 - I. Branch
 - J. Position the plastic locking tie between the projections as shown in the illustration.
 - K. Projection
 - L. Allowance 2.0 mm (0.08 in) or less
 - M. Direction of upper surface of the engine
 - N. Install the lock of the plastic locking tie as shown in the illustration.

WIRE ROUTING DIAGRAM

LEFT SIDE VIEW



WIRE ROUTING DIAGRAM


- | | |
|--------------------------------------|-------------------------------------|
| 1. Rectifier/regulator | 15.Fuse (10 A) coupler |
| 2. Earth terminal | 16.Fuse (30 A) coupler |
| 3. ECU | 17.Starter motor |
| 4. ECU coupler (black) | 18.Plastic locking tie |
| 5. ECU coupler (gray) | 19.Throttle body |
| 6. Fuel injector #1 lead | 20.Throttle position sensor lead |
| 7. Ignition coil #1 lead | 21.Engine temperature sensor lead |
| 8. Throttle position sensor coupler | 22.O ₂ sensor lead |
| 9. Engine temperature sensor | 23.Starter motor lead |
| 10.Engine temperature sensor coupler | 24.Starter relay lead |
| 11.O ₂ sensor coupler | 25.Rectifier/regulator lead (white) |
| 12.Spark plug cap | 26.Rectifier/regulator lead (red) |
| 13.Stay | 27.Rectifier/regulator lead (black) |
| 14.Fuse (10 A) coupler | |

- A. Tighten the earth terminal together with the mounting bolt in the direction shown in the illustration.
- B. Install the spark plug cap in the direction shown in the illustration.
- C. Install in the stay.
- D. Tighten together with the vehicle battery positive terminal.
- E. Direction of upper surface of the engine
- F. Allowance 2.0 mm (0.08 in) or less
- G. Install the leads so that they do not overlap each other.
- H. Starter motor lead installation details
- I. Engine side
- J. Rectifier/regulator lead installation details
- K. Connect with the stator lead connector (female). (Polarity does not matter)
- L. Connect with the wire harness connector (male/black).
- M. Connect with the wire harness connector (male/red).

WIRE ROUTING DIAGRAM

RIGHT SIDE VIEW

7
SPECIFICATIONS




WIRE ROUTING DIAGRAM

1. Hose clamp
2. Low-pressure fuel pump
3. Fuel delivery hose
4. Fuel injector pipe 1
5. Fuel hose
6. High-pressure fuel pump

7. Fuel filter
8. Plastic locking tie
9. Lead 1
10. Purge hose 1
11. Pulsar hose


- A.
 - Install the air filter case cover as shown in the illustration.
 - The locking claw should be fixed securely to the groove of the case.
- B. Insert the hose until it reaches the end as shown in the illustration.
- C. Install white painted portion in the direction shown in the illustration.
- D. Install the plastic locking tie at the position shown in the illustration.
- E. Fuel delivery hose installation details
- F. Install with the yellow painted portion on top.
- G. The position of the binding area of the plastic locking tie should be on the engine side.
- H. Keep the length shown in the illustration to 0–2.0 mm (0–0.08 in) and cut off the end of the plastic locking tie.
- I. Pulsar hose installation details
- J. Install the yellow painted portion in the direction shown in the illustration.

WIRE ROUTING DIAGRAM



- | | |
|---------------|---------------|
| 1. Oil hose 1 | 4. Oil hose 2 |
| 2. Oil cooler | 5. Oil filter |
| 3. Hose clamp | |
-
- A. Insert the oil hose all the way into the oil cooler.
 - B. Face the projection inward.
 - C. Install the white painted portion in the direction shown in the illustration.
 - D. 8–12 mm (0.31–0.47 in)
 - E. Install the hose clamp in the direction shown in the illustration.
 - F. Install the yellow painted portion in the direction shown in the illustration.
 - G. 2.0–4.0 mm (0.08–0.16 in)
 - H. Face the projection outward.



WIRE ROUTING DIAGRAM



- | | |
|---------------------------------|------------------------------------|
| 1. Fuel injector #2 lead | 5. High-pressure fuel pump coupler |
| 2. Ignition coil #2 lead | 6. Oil pressure switch |
| 3. High-pressure fuel pump lead | 7. Oil pressure switch lead |
| 4. Purge hose | 8. Spark plug cap |
- A. The high-pressure fuel pump coupler should be laid along the purge hose.
 B. Install the spark plug cap in the direction shown in the illustration.
 C. Oil pressure switch lead routing direction
 D. Direction of upper surface of the engine

WIRE ROUTING DIAGRAM

REAR SIDE VIEW




WIRE ROUTING DIAGRAM

1. Air filter cover 1
 2. Air filter case stay
 3. Breather hose
 4. Joint 2
 5. Air filter case
- A. Install the air filter case stay into the groove in the air filter case.
 - B. Install the screw in the direction shown in the illustration.
 - C. Insert the protector side of the purge hose 1 all the way into the pipe of the throttle body.
 - D. 19–21 mm (0.75–0.83 in)
 - E. Install the white painted portion in the direction shown in the illustration.
 - F. Insert the breather hose all the way into the pipe of the joint 1.
 - G. Insert the joint 2 until it contacts the projection on the joint 1.
 - H. 2.0–4.0 mm (0.08–0.16 in)
 - I. Insert the air filter cover 1 until it contacts the air filter case.
 - J. Installation angle of joint 2 15.75° (reference value)
 - K. Install the joint 2 in the direction shown in the illustration.
 - L. Insert from 22 mm (0.87 in) until contact is made as shown in the illustration.
 - M. The air filter case and joint 2 should not be bent or detached due to unreasonable installation.
 - N. Install the air filter case in the direction shown in the illustration.
 - O. 5–7 mm (0.20–0.28 in)

WIRE ROUTING DIAGRAM

7

SPECIFICATIONS




- | | |
|--|--------------------------|
| 1. Manifold absolute pressure sensor coupler | 5. Plastic locking tie |
| 2. Manifold absolute pressure sensor | 6. Inlet manifold |
| 3. Clamp | 7. Ignition coil #1 lead |
| 4. O ₂ sensor coupler | 8. Fuel injector #1 lead |
-
- | |
|--|
| A. FI diagnostic tool coupler |
| B. Main switch coupler |
| C. Direction of upper surface of the engine |
| D. Allowance 2.0 mm (0.08 in) or less |
| E. Install the plastic locking tie as shown in the illustration. |
| F. • Install the leads so that they do not overlap each other. |
| • The leads should not interfere with the side of the fan case. |

MEMO

APPENDIX

CIRCUIT DIAGRAM



-
1. ECU (Engine Control Unit)
 2. Stator coil assembly
 3. Rectifier/regulator
 4. Fuse (30 A)
 5. Fuse (10 A)
 6. Fuse (10 A)
 7. Oil pressure switch
 8. Starter relay
 9. Starter motor
 10. Battery
 11. Main switch
 12. Mil light
 13. Oil warning light
 14. Rollover switch
 15. FI diagnostic tool coupler
 16. Engine temperature sensor
 17. Manifold absolute pressure sensor
 18. Throttle position sensor
 19. O₂ sensor
 20. Crankshaft position sensor
 21. High-pressure fuel pump
 22. Ignition coil #2
 23. Ignition coil #1
 24. Fuel injector #1
 25. Fuel injector #2

Color code

B	Black	G/R	Green/Red
Br	Brown	G/W	Green/White
G	Green	G/Y	Green/Yellow
Gy	Gray	L/O	Blue/Orange
L	Blue	L/W	Blue/White
O	Orange	P/L	Pink/Blue
R	Red	R/L	Red/Blue
V	Violet	R/W	Red/White
W	White	R/Y	Red/Yellow
Y	Yellow	W/B	White/Black
B/W	Black/White	W/R	White/Red
Br/G	Brown/Green	Y/L	Yellow/Blue

MEMO

